

PRICE: \$25.00

INSTRUCTIONS for SLO-SYN MICRO SERIES OPEN LOOP PACKAGED PROGRAMMABLE INDEXERS

Superior Electric reserves the right to make engineering refinements on all its products. Such refinements may affect information given in instructions. Therefore, **USE ONLY THE INSTRUCTIONS THAT ARE PACKED WITH THE PRODUCT.**

INSPECTION

When unpacking the indexer, examine it carefully for any shipping damage. The "Damage and Shortage" instruction packed with the unit outlines the procedure to follow if any parts are missing or damaged.

FIRST USE
TRY TO DEENERGIZE:
echo '<008>' /dev/cua0
echo 'H36' /dev/cua0

ALL LISTEN/ACTIVE

DEENERGIZE

NOTE:


- ① H35 = ENERGIZE
- ② IN "ALL LISTEN MODE", NO TRANSMISSIONS FROM SLO-SYN. ASSIGN AN ID FIRST!

SUPERIOR ELECTRIC
WARNER ELECTRIC




EIA RS274-D

DB9 LINUX CABLE



DB25 LINUX CABLE

DB9 SLO SYN



WALKMAN IN NYK
212876 2341

AI 395@Fresno, Carleton, Ca

TABLE OF CONTENTS

	Page		Page
SECTION 1: SCOPE AND OBJECTIVES			
		F Code	5-18
1.1 Using This Manual	1-1	L Codes	5-19
1.2 Product Features	1-1	H Codes	5-20
1.3 Logic Voltage And Programming Conventions	1-2	Initialization	5-21
SECTION 2: EXPRESS START UP PROCEDURE		SECTION 6: RS232 COMMANDS	
	2-1	6.0 General Programming Information	6-1
 		Buffering Of Commands	6-1
SECTION 3: INSTALLATION GUIDELINES		Xon/Xoff Protocol	6-1
3.1 Mounting	3-1	Device Identification	6-2
3.2 Connector Locations And Pin Assignments	3-1	Device Activation	6-2
Parallel I/O Connections	3-1	Listen Mode	6-2
Serial I/O Connections	3-2	General Programming Comments	6-3
3.3 Memory Protect Switch	3-4	6.1 L Code Descriptions	6-5
 		L06, Execution Format	6-5
SECTION 4: SPECIFICATIONS		L07, Strobe Delay	6-6
4.1 Inputs And Outputs	4-1	L08, <i>Mechanical Home</i> Direction	6-6
4.2 Environmental Specifications	4-1	L09, Jog Speed	6-7
 		L11, Accel/Decel	6-8
SECTION 5: PARALLEL PORT OPERATION		L12, <i>Low Speed</i>	6-9
5.1 Parallel Port Data Assignments	5-1	L13, Step Increment	6-10
5.2 Strobed Input Signals	5-5	L14, Home Speed	6-11
All Windings Off	5-5	L16, <i>Index</i> From Run Travel Limit	6-12
Clear	5-5	L17, Offset From <i>Mechanical Home</i>	6-12
Clockwise (CW) Direction	5-6	L18, Clockwise Software Travel Limit	6-13
Clockwise (CW) Limit	5-7	L19, Counterclockwise Software Travel Limit	6-13
Counterclockwise (CCW) Direction	5-8	L20, Up/Down Feed Rate Override	6-14
Counterclockwise (CCW) Limit	5-9	L21, Device Identification Number	6-14
Cycle Start	5-9	L22, <i>Baud Rate</i>	6-14
Feed Hold	5-10	L23, Character Length	6-15
Home Limit/Index from Run	5-10	L25, RS232 Parity	6-15
Input 1	5-10	L26, Command Acknowledgement	6-16
Input 2	5-10	L41, Auto Start Line Number	6-17
Load	5-11	L43, Delay Between <i>Index</i> And <i>Backlash</i>	6-17
Low/High	5-12	L44, Program Line Delay	6-17
Serial/Parallel	5-13	L45, Limit Switch Enable	6-18
Step/Jog	5-13	L47, Repeat Count	6-18
Stop Cycle	5-14	L48, Program Line Count Designator	6-19
5.3 Load Cycle Input Signals	5-14	L49, Parameter Transfer Designator	6-20
Code Inputs	5-14	L50, Parameter Transfer Count	6-21
Data Inputs	5-14	L51, Input/Output Mode Select	6-22
SEL 1, SEL 2, SEL 4	5-14	L52, Buffer Warning Character	6-24
+ Sign/- Sign	5-14	L55, Line Done Character	6-24
5.4 Programmable Registers	5-15	L56, Program Done Character	6-25
Line Number Loading	5-15	L57, Strobe 0, Strobe 1 Delay	6-25
G Codes	5-16	L66, <i>Backlash</i> Compensation	6-26
X Code	5-17	L67, Auto Reverse	6-26
		L70, Resolution	6-27
		L71, Ramp Frequency Limit	6-28

	Page		Page
L72, Ramp Profile Select	6-28	6.3 G Codes, Preparatory	
L73, Deviation Frequency	6-30	Commands	6-51
L98, Delay Between Continuous H Code Transmissions	6-30	G04, Dwell Time	6-52
6.2 H Code Descriptions	6-31	G10, Start <i>Index</i> From Run	6-53
H01, Cycle Start	6-31	G11, Call a Subroutine	6-54
H02, <i>Step Mode</i>	6-31	G12, Go To Line Number	6-54
H03, <i>Jog Mode</i>	6-32	G20, Conditional Branch	6-55
H04, <i>High Speed Mode</i>	6-32	G22, Wait For Input	6-57
H05, <i>Low Speed Mode</i>	6-33	G23, Increment Jog Cycle Frequency	6-59
H06, CW Direction	6-34	G24, Decrement Jog Cycle Frequency	6-60
H07, CCW Direction	6-35	G25, Loop Start	6-61
H08, Return To <i>Electrical Home</i>	6-35	G26, Loop End	6-61
H09, Set <i>Electrical Home</i>	6-36	G27, <i>High Speed Mode</i>	6-62
H10, Return To <i>Mechanical Home</i>	6-36	G28, <i>Low Speed Mode</i>	6-62
H11, Clear Program Line	6-37	G29, Preload Designated Parameter	6-63
H12, Clear Program Lines Using L48	6-37	G30, End Of Program	6-64
H13, Transfer Program Line	6-37	G31, Program Stop	6-64
H14, Transfer Program Lines Using L48	6-37	G32, Return From Subroutine	6-65
H15, Transfer Current Line Number	6-38	G36, Strobe X Code Data	6-65
H16, Transfer Parameters	6-38	G37, Strobe N Code Data	6-66
H17, Transfer Absolute Electrical Position	6-38	G38, Strobe F Code Data	6-66
H18, Transfer Motion Status	6-39	G47, Set Output Condition	6-67
H19, Transfer Mode Status	6-39	G48, Start Jog Cycle	6-68
H20, Transfer Output Status	6-40	G49, Stop Jog Cycle	6-69
H21, Transfer Conditional Input Status	6-40	G64, Enable Reduce Current	6-70
H23, Transfer Software Revision Level	6-41	G65, Disable Reduce Current	6-70
H24, Program Trace Mode On	6-41	G66, Enable Boost Current	6-71
H25, Program Trace Mode Off	6-41	G67, Disable Boost Current	6-71
H28, Transfer Switch Input Status	6-42	G68, Motor Windings Off	6-72
H29, Transfer Program Execution Time	6-42	G69, Motor Windings On	6-72
H30, Start <i>Index</i> From Run Cycle	6-43	G76, Return To <i>Electrical Home</i>	6-73
H31, Target Velocity Increase	6-43	G77, Set <i>Electrical Home</i>	6-73
H32, Target Velocity Decrease	6-44	G78, Return To <i>Mechanical Home</i>	6-74
H33, Incremental Position Mode	6-44	G79, Preload Absolute Position	6-75
H34, Absolute Position Mode	6-44	G90, Absolute Position Mode	6-75
H35, Motor Windings On	6-44	G91, Incremental Position Mode	6-75
H36, Motor Windings Off	6-45	6.4 Line Data Codes	6-76
H37, Enable Boost Current	6-45	N, Line Number	6-76
H38, Disable Boost Current	6-45	X, Program Move And Direction	6-78
H39, Enable Reduce Current	6-46	F, Program <i>High Speed Feed Rate</i>	6-79
H40, Disable Reduce Current	6-46	6.5 Miscellaneous Commands	6-80
H41, Transfer Remaining Repeat Value	6-46	*, Clear	6-80
H60, Transfer Present Velocity	6-47	\$, Feed Hold	6-80
H85, Transfer Motion Error Status	6-47	#, Program Stop	6-80
H86, Transfer Data Error Status	6-48		
H87, Transfer Program Error Line	6-49		
H88, Transfer Active Cycle	6-49		
%, Activate Continuous H Code Transfer Mode	6-50		
		SECTION 7: DEDICATED SIGNAL	
		OUTPUTS	
		All Windings Off	7-1
		CW/CCW	7-1
		Motion Busy	7-1
		Position Error	7-1
		Power Supply Common	7-2
		Pulse	7-2

	Page
APPENDIX A: L Code Listing and <i>Default</i> Listing	AP-1
APPENDIX B: H Code Listing	AP-4
APPENDIX C: Immediate Commands	AP-5
APPENDIX D: Miscellaneous Commands	AP-6
APPENDIX E: G Code Listing	AP-7
APPENDIX F: Program Worksheets	AP-8
APPENDIX G: Cable Information	AP-9
APPENDIX H: Typical PLC Interface	AP-10
APPENDIX I: Application Program Example	AP-11

GLOSSARY	G-1
----------	-----

LIST OF FIGURES

Figure 3.1 Connector Locations	3-1
Figure 3.2 Typical Wiring for <i>Open</i> <i>Collector</i> Output	3-2
Figure 3.3 Single Indexer Serial Port Connections	3-3
Figure 3.4 <i>Daisy Chain</i> Connections	3-3
Figure 5.1 Connection Diagram, Strobed Inputs with L51= 0 to 3	5-2
Figure 5.2 Connection Diagram, Strobed Inputs with L51= 4 to 7	5-3
Figure 5.3 Strobed Input Timing	5-4
Figure 6.1 PC Program Flow Chart for Indexer Communications	6-3
Figure 6.2 Trapezoidal Ramp Profile	6-29
Figure 6.3 "S" Ramp Profile	6-29
Figure 6.4 Hyperbolic Ramp Profile	6-29
Figure H1A Typical Switch Panel Connection	AP-10
Figure H1B Corresponding PLC Interface	AP-10
Figure I-1 Application Program Example	AP-11
Figure I-2 Diagram of Application Example	AP-13

NOTE: TERMS WHICH APPEAR IN ITALICS IN THIS MANUAL ARE DEFINED IN THE GLOSSARY.

SECTION 1: SCOPE & OBJECTIVES

1.1 USING THIS MANUAL

It is important that you understand how the Programmable Indexer is programmed and operated before you install and use the unit. **We strongly recommend that you read this manual completely before proceeding with the installation of this unit.**

A SLO-SYN Micro Series Programmable Indexer can be operated from a Switch Panel or an SSP-100 Programmer via the 25-pin parallel data port. It can also be operated from a terminal or host computer via the RS232 serial data port, or from the Superior Electric SSP-525 Hand-Held Programmer.

If a Switch Panel or SSP-100 Programmer is to be used, you need to refer to Section 3 for connector locations and pin assignments, to Section 4.2 for I/O specifications, to Section 5 for additional connection information as well as for information on how to operate the Indexer, and to Section 7 for dedicated output information. If RS232 communication is not to be used with the Indexer, it is not necessary to read Section 6.

When the Indexer is to be operated through the RS232 serial port, it is not necessary to read Section 5. You will find connections for the RS232 port listed in Section 3 and specifications for the inputs and outputs listed in Section 4. It is also important that you read Section 6 thoroughly to learn how to program and operate the Indexer. Dedicated outputs are also described in Section 7. An application example and elementary programming information are given in Appendix I.

1.2 PRODUCT FEATURES

SLO-SYN Programmable Indexers are designed to be operated from a simple switch panel which can be easily interfaced with the indexer. If desired, the SSP-100 Programmer can be ordered to accomplish control of a Programmable Indexer. The SSP-100 plugs into the 25-pin parallel data port of the indexer to provide complete control of most programming and operating functions of the units. A Programmable Indexer can also be operated from a terminal or host computer via the RS232 serial data interface port, or it can be controlled from an SSP-525 Hand-Held Programmer.

Note: limited parallel and serial communication may be in operation at the same time. Refer to the Serial/Parallel Input Signal (Section 5.2) for restrictions of simultaneous operation.

Advanced Features Of SLO-SYN Micro Series Programmable Indexers

Micro Series Programmable Indexers have a number of features that can enhance the operation of the system. These features are:

- Choice of absolute or incremental motion
In the incremental mode, all positioning moves are specified from the present location. In the absolute mode, all positioning information is given relative to a zero, or "home" position.

- Boost or Reduce motor current (3180 and 6180 models only)

The Boost Current function provides higher current to the motor windings when additional power is needed for accelerating heavy loads. The Reduce Current function allows the motor phase current to be lowered to decrease heating of the motor when maximum power is not necessary.

- Auto Reverse

When the Auto Reverse feature is active, the Indexer automatically returns the motor to the starting point at the end of each move.

- Auto Repeat

The operator can program the Repeat Count register with the number of times a program is to be repeated. The indexer will perform the program once, plus the number of times entered in the Repeat Count register. If the number in the register is zero, the indexer will perform the program only once.

- All Windings Off

When holding torque is not needed while the motor is at rest, the All Windings Off function can be activated to shut off current to the windings when the motor comes to a stop, thereby lessening motor heating. This function is only active when the motor is not moving.

It is important to note that all holding torque is lost when the Windings Off function is active.

H35 - ON
H36 - OFF

- Choice of ramp profiles

Depending on the type of motion required, the operator can specify that the motion be done using a trapezoidal, "S" or hyperbolic ramp profile.

- *Index From Run cycle*

Index the commanded distance during a continuous motion upon recognition of the "Home Limit" input.

- Velocity Changing during Motion

Velocity may be changed during motion via RS232 commands, "!Fnnnnnnn, !H31, !H32, !H4 or !H5", or a transition of the "Low/High" switch input.

- RS232 Operation

A Micro Series Programmable Indexer can also be directed via the RS232 serial data communications port from a terminal or host computer, or via the SSP-525 Hand-Held Programmer. The command set allows full control of all aspects of Indexer programming and operation.

1.3 Logic And Programming Conventions

All logic is LOW TRUE. This means that a logic signal is **active** when low and inactive when high. **Low true signals are designated by a bar over the signal name, such as OUTPUT1**. A signal is brought low by connecting its output terminal to signal common.

If a logic control signal is left open, the function will be clamped in a high or inactive condition.

When a sign is to be used in conjunction with a move distance or an offset direction, + will cause clockwise motion as viewed from the label end of the motor.

Certain commands are designated as MODE commands. Examples include: ABSOLUTE MODE, INCREMENTAL MODE, STEP MODE, JOG MODE, etc. Care should be taken to assure that the correct MODE is operational for each command. Once a mode is set, it remains active until canceled or until an alternate mode is chosen.

Motion performance and the ranges listed for motion parameters are dependent on the translator resolution chosen.

SECTION 2: EXPRESS START UP PROCEDURE

The following instructions describe the minimum steps necessary for the **Indexer** portion of the unit to become operational. Be sure to refer to the Express Start Up Procedure for the Drive section and follow the drive requirements. **FAILURE TO PERFORM THESE STEPS MAY RESULT IN DAMAGE TO THE UNIT.**

This Indexer Manual MUST BE READ IN ITS ENTIRETY to correctly operate the Indexer. This Express Start Up Procedure only highlights the important items necessary to ensure correct Indexer operation.

AC POWER MUST BE OFF

- 1) Refer to the manual for the Drive portion of your unit and follow the steps listed there for installation of the Drive.
- 2) Define the primary mode of operation (Serial or Parallel).

The Indexer can be operated in the Parallel mode from an external user supplied switch panel or from a Superior Electric model SSP-100 Programmer. The switch panel or SSP-100 Programmer connects directly to the 25-pin "D" type connector provided for parallel data entry. Refer to Section 3.2 for further details. See Section 4.2 for voltage and current specifications, to Section 5 for descriptions of the Parallel mode commands and registers and to Section 7 for descriptions of the dedicated outputs.

No connections are required on the *Parallel I/O* connector to operate the Indexer in the Serial mode. Refer to Section 4.2 for voltage and current specifications and to Section 6 for descriptions of commands for Serial operation. Section 7 describes the dedicated outputs.

TURN THE AC INPUT POWER ON

- 3) **Set up indexer parameters** starting with the resolution (L70) value. A List of factory *defaults* is listed in APPENDIX A. If the factory *default* values are acceptable proceed to the next step. Otherwise, change the desired parameters.

- 4) **Define your application requirements** (speeds, move distances, delays, etc).
- 5) Draw a **flowchart or pseudo code application** program flow.
example:
N1 X+1000 F1000 (Move +1000 steps @ 1000 pps)
N2 G04 X1000 (delay 1 second)
N3 G47 X01 (turn Output 1 On and Output 2 Off)
N4 G30 (End of Program)

Note: Refer to APPENDIX I for an Application Example and elementary programming information.

- 6) **Use the Program Worksheets** in APPENDIX F.
- 7) **Program the Indexer lines** (1 to 400) to execute the developed flowchart or pseudo code.

SECTION 3: INSTALLATION GUIDELINES

3.1 MOUNTING

The Programmable Indexer is mounted by fastening its mounting brackets to a flat surface. The mounting brackets can be located in either of two positions. Please refer to the manual for the Drive for the proper mounting procedure.

3.2 CONNECTOR LOCATIONS AND PIN ASSIGNMENTS

Connector locations are shown in Figure 3.1.





Figure 3.1, Connector Locations

Parallel I/O Connections

Parallel I/O connections are made through a 25-pin "D" type female connector. For maximum noise immunity, a shielded, twisted cable no longer than 20 feet (6.1 m) should be used to connect a parallel device.

The connector pin assignments are as follows:

Pin	Assignment
1	Signal Common (Vo)
2	D7 Input
3	D5 Input
4	D3 Input
5	D1 Input
6	MOTION BUSY Output *
7	STROBE 7
8	STROBE 5
9	STROBE 3
10	STROBE 1
11	OUTPUT 2 *
12	ALL WINDINGS OFF Output*
13	CW/CCW Output *
14	Signal Common (Vo)
15	D6 Input
16	D4 Input
17	D2 Input
18	D0 Input
19	POSITION ERROR Output*
20	STROBE 6
21	STROBE 4
22	STROBE 2
23	STROBE 0
24	OUTPUT 1*
25	PULSE Output *




* These outputs are *open collectors*. If monitored, they must be pulled up to an external voltage source (+24 Vdc maximum) through a series resistor to limit the sink current to a maximum of 40 milliamperes (refer to Figure 3).

The strobe outputs are also *open collectors*. If they are connected directly to the indexer inputs, pull up resistors are not needed.

When connecting inductive loads such as relays to an output, be sure to use clamp diodes as shown in Figure 3.2.

Signal line filtering has been incorporated to help keep electrical interference from affecting Indexer operation. Because of this, it is not possible to use the Pulse Output signal (pin 25 on the 25-pin connector) when operating in the 1/125 microstep mode. The pulse output on this pin is not affected when operating in the full-step, half-step, 1/5 or 1/10 microstep modes. A maximum pull-up impedance of 3.9k ohms should be used when utilizing the Pulse Output.

Note that the Indexer can still operate in the 1/125 microstep mode. This limitation only affects connection to external drives via the 25-pin connector.



NOTE: Calculate pull-up resistor value based on voltage of external dc power supply to limit "sink" current to 40 mA into OUT 1 or OUT 2.

$$\text{Example: } R = \frac{V}{I} = \frac{24}{0.040} = 600 \text{ ohms for } V_{dc} = 24 \text{ Vdc}$$

Figure 3.2, Typical Wiring For Open Collector Output

Serial I/O Connections

Serial I/O connections are made through a 9-pin "D" type female connector.

For maximum noise immunity, a cable with shielded, twisted pairs no longer than 50 feet (15.2 m) should be used.

The wire size should be 24 AWG.

The connector pin assignments are as follows:

Pin Assignment

- 1 Signal Common (Vo)
- 2 RS232 Chain Out (Tx)
- 3 RS232 Receive Data (Rx)
- 4 Signal Common (Vo)
- 5 Signal Common (Vo)
- 6 RS232 Echo
- 7 RS232 Chain In
- 8 +5 Vdc *
- 9 +5 Vdc *

* Note that the +5V is brought out to the connector to power the Superior Electric hand-held programmer. These pins should not be populated on a cable to be used to connect the Indexer to another serial device.

Serial communications can be made with one Indexer as shown in Figure 3.3, or in a *daisy chain* configuration as shown in Figure 3.4.

The following chart shows the maximum number of Indexers which can be daisy chained when communicating at the specified *baud rate*.

BAUD RATE CHART

Baud	Maximum Number Of Daisy Chained Indexers
9600	10
2400	40
1200	80
300	99




Figure 3.3, Single Indexer Port Connections




Figure 3.4, Daisy Chain Connections

NOTE: When setting up a *daisy chain* configuration, each Indexer must be given a unique address prior to wiring the system. Refer to Section 6.0, "Device Identification", for programming instructions.

3.3 Memory Protect Switch

All Micro Series Indexers incorporate a hardware Memory Protect Switch to help prevent accidental program or parameter changes. When the switch is in the **"Protect"** position, changes to the program or the parameters will not be allowed. Such changes can be made by placing the switch in the **"Write"** position.

The Memory Protect Switch is located in the grounding strap midway between the 9-pin and the 25-pin filter "D" type connectors (see Figure 3.1). When this switch is positioned toward the 25-pin connector, the Indexer is in the **"Write"** mode. It is in the **"Protect"** mode when the switch is positioned toward the 9-pin connector. The switch is in the **"Write"** mode when the Indexer is shipped from the factory.

In all but the most severe environments, it will not be necessary to use the Memory Protect Switch. However, some users may wish to use the protect feature to prevent unauthorized access to the Indexer program or parameters.

SECTION 4: SPECIFICATIONS

4.1 Inputs and Outputs

NOTE: Failures of the Indexer's I/O circuitry may occur if voltages which are negative with respect to signal common appear on inputs and outputs.

Switch Panel Operation

Output Signal Parameters (*open collector*)

POSITION ERROR, MOTION BUSY, OUTPUT 1, OUTPUT 2, PULSE, CW/CCW, ALL WINDINGS OFF, STROBE 0 Through STROBE 7

High Level Output Voltage:	+24 Vdc max., <i>open collector</i>
High Level Leakage Current:	250 microamperes. max.
Low Level Output Voltage:	+0.4 Vdc max @ 16 milliamps sink
	+0.7 Vdc max @ 40 milliamps sink

Input Signal Parameters D0 through D7

High Level Input Voltage:	+8.5 Vdc minimum +15 Vdc maximum
High Level Leakage Current:	1 milliamps maximum
Low Level Input Voltage:	+0.0 Vdc minimum +6.5 Vdc maximum
Low Level Leakage Current:	3.5 milliamps maximum

RS232 Serial Port Operation

RS232 Signal Characteristics:

Output Voltage Swing:	+/-5 Vdc minimum +/-10 Vdc maximum
Input Voltage Range:	-30 Vdc minimum +30 Vdc maximum

4.2 ENVIRONMENTAL SPECIFICATIONS

Operating Temperature:	+32 degrees F to +122 degrees F (0 degrees C to +50 degrees C) free ambient
Storage Temperature:	-40 degrees F to +167 degrees F (-40 degrees C to +75 degrees C)
Humidity:	95% max noncondensing
Altitude:	10,000 feet (3048 m) max.

SECTION 5 PARALLEL PORT OPERATION

5.1 PARALLEL PORT DATA ASSIGNMENTS

SLO-SYN Programmable Indexers are designed to be programmed and directed using external switches. A function is activated by connecting one of the DATA 0 through DATA 7 pins to one of the STROBE 0 through STROBE 7 pins. The chart of Parallel Port I/O Assignments below shows the pin assignments for each indexer function.


PARALLEL PORT I/O ASSIGNMENTS

INPUT	STROBE 0 (pin 23)	STROBE 1 (pin 10)	STROBE 2 (pin 22)	STROBE 3 (pin 9)	STROBE 4 (pin 21)	STROBE 5 (pin 8)	STROBE 6 (pin 20)	STROBE 7 (pin 7)
$\overline{D0}$ CW Limit (pin 18)	CW Dir		Code 1	Code 100	Data 1M	Data 10K	Data 100	Data 1
$\overline{D1}$ CCW Limit (pin 5)	CCW Dir		Code 2	Code 200	Data 2M	Data 20K	Data 200	Data 2
$\overline{D2}$ Home Limit (pin 17)	Load		Code 4	Code 400	Data 4M	Data 40K	Data 400	Data 4
$\overline{D3}$ Clear Cycle (pin 4)	AWO		Code 8	Code 800	Data 8M	Data 80K	Data 800	Data 8
$\overline{D4}$ Feed Hold (pin 16)	Low/High		Code 10	Sign	Data 10M	Data 100K	Data 1K	Data 10
$\overline{D5}$ IN 1 (pin 3)	Step/Jog		Code 20	Sel 1	Data 20M	Data 200K	Data 2K	Data 20
$\overline{D6}$ IN 2 (pin 15)	Cycle Start		Code 40	Sel 2	Data 40M	Data 400K	Data 4K	Data 40
$\overline{D7}$ Stop Cycle (pin 2)	Ser/Par		Code 80	Sel 4	Data 80M	Data 800K	Data 8K	Data 80

NOTE: During the strobing of external data, (Strobes 2 - 7), all commands associated with Strobes 0 and 1 are ignored.


NOTE: All signals are active (connect appropriate data and strobe pins) except LOW, STEP and SER which are active high (e.g., no connection between data and strobe pins).

For example, the CYCLE START function is shown in the Strobe 1 vertical column and in the Data 6 horizontal column. Therefore, the Cycle Start function can be activated by connecting the Data 6 pin (pin 15 on the 25-pin connector) to the Strobe 1 pin (pin 10 on the 25-pin connector) via a user supplied diode. A typical circuit for activating this input is shown.




Typical Circuit For Activating CYCLE START Function

All functions which are listed in the Strobe 0 and Strobe 1 columns are available whenever the Load function is not activated. The Indexer repeatedly strobes, in sequence, the inputs connected to Strobe 0 and then Strobe 1. The connection diagram for this strobed input cycle is given in Figure 5.1 and 5.2 and the timing diagram is given in Figure 5.3.




INPUT ASSIGNMENT				
L51 VALUE	AWD	STEP/JOG	CCW DIR	CW DIR
0	AWD	STEP/JOG	CCW DIR	CW DIR
1	AWD	IN 7	IN 6	IN 5
2	IN 8	STEP/JOG	CCW DIR	CW DIR
3	IN 8	IN 7	IN 6	IN 5

Figure 5.1, Connection Diagram, Strobed Inputs with L51= 0 to 3



INPUT ASSIGNMENT				
L51 VALUE	AWO	STEP/JOG	CCW DIR	CW DIR
4	AWO	STEP/JOG	CCW DIR	CW DIR
5	AWO	IN 7	IN 6	IN 5
6	IN 8	STEP/JOG	CCW DIR	CW DIR
7	IN 8	IN 7	IN 6	IN 5

Figure 5.2, Connection Diagram, Strobed Inputs with L51= 4 to 7



(Drawing)

Figure 5.3, Strobed Input Timing

Functions in the Strobe 2 through Strobe 7 columns are only activated during a Load cycle. When the Load command is given, the Indexer disables Strobes 0 through 1 and enables Strobes 2 through 7. All inputs connected to these strobe pins will then be input into the Indexer in sequence, beginning with those connected to Strobe 2.

After inputting the data connected to Strobe 7, the Indexer will return to sequencing the Strobe 0 and Strobe 1 inputs.

Selection of specific registers for entry of data during a Load cycle is done using the Select 1, Select 2 and Select 4 inputs. The data to be entered into a register is selected using the various Code and Field Data inputs. The Register Selection Chart shows how the Select inputs are used to select the available programmable registers.

REGISTER SELECTION CHART

SEL 4	SEL 2	SEL 1	Function Selected	Data
0	0	0	N Line Number	Code nnn
0	0	1	G Code	Code 0nn
0	1	0	X Code (Note 1)	Field snnnnnnnn
0	1	1	F Code (Note 1)	Field nnnnnnn
1	0	0	L Code (Note 1)	Code 0nn, Field snnnnnnnn
1	0	1	H Code	Code 0nn
1	1	0	Initialization	Code 099, Field nnn
1	1	1	Not Used	None

0= input inactive; 1= input active; s= sign input; n= 0 to 9;
Code= Code Data Field; Field= Strobe 4 through Strobe 7 data inputs.

Note 1: This register will be ignored if L51 = 4 to 7.


5.2 STROBED INPUT SIGNALS

The following inputs are available whenever the Load input is NOT activated.

NOTE: All inputs must be active for a minimum of 3 times the L57 delay to be recognized by the Indexer as valid input signals.

All Windings Off

Switch Closure:



Function:

If L51=0,1,4,5
When the All Windings Off input is active, motor winding current will be removed when motion ceases.

CAUTION:

The motor has no holding torque when the All Windings Off input is active.


If L51=2,3,6,7
This signal is used as programmable input 8 for a G20 or G22 line command.

Notes:

Whenever the All Windings Off input is active, an additional time delay is introduced during programmed motion cycles. This delay allows winding current to build in the motor prior to the start of motion and to decay after motion has occurred. The delay is approximately 50 milliseconds prior to motion and 50 milliseconds after motion has stopped. Therefore, the shortest time between moves is approximately 100 milliseconds.

Clear

Switch Closure:



Function:

Activating the Clear input will cause an immediate termination of the current operation.

Notes:

When the Clear input is activated, any motion that is taking place will come to an immediate stop. **This may result in an inaccurate absolute position count.**

If the Clear input is activated while a program cycle is active, the program cycle will be terminated.

If data is being loaded, the load sequence will be terminated and the register being loaded will retain the previously loaded data.

If a delay is occurring, the delay will be terminated.

Clockwise (CW) Direction

Switch Closure:



Function:

If L51=0,2,4,6

Activating the CW Direction input will start motion in the clockwise direction.

If L51=1,3,5,7

This signal is used as programmable input 5 for a G20 or G22 line command.

Notes:

Serial/Parallel must be active (Parallel mode).

If any motion other than CW manual motion is active or if a Program Cycle is active, the CW Direction Input will not be honored.

The following chart lists the action which will occur with the possible combinations of inputs that affect CW Direction.

INPUTS THAT AFFECT CW OPERATION			
CW INPUT	STEP/JOG INPUT	LOW/HIGH INPUT	FUNCTION
active	active	active	Ramp to Jog Speed rate and Jog
active	active	inactive	Jog at <i>Low Speed rate</i>
active	inactive	active	Ramp to Jog Speed rate and Step
active	inactive	inactive	Step at <i>Low Speed rate</i>
active	active or inactive	inactive to active	Ramp to Jog Speed rate
active	active or inactive	active to inactive	Ramp to <i>Low Speed rate</i>

Related Inputs:

Step/Jog
Low/High

Clockwise (CW) Limit

Switch Closure:



Function:

If L45=0

The CW Limit input is used to indicate the end of the allowable travel in the CW direction.

If L45=1

This signal is used as programmable input 3 for a G20 or G22 line command.

Notes:

The CW Limit is usually activated by a switch that closes when the system reaches the end of permissible travel in the CW direction.

During motion, the Indexer tests this input for the switch closure. If the switch closure occurs, any motion that is taking place in the CW direction will come to an uncontrolled stop. **When this happens, an inaccurate absolute position count may result.**

When the CW Limit input is activated during a program cycle, the program cycle will be terminated.

Motion will only be allowed in the CCW direction as long as the CW Limit input remains active.

COUNTERCLOCKWISE (CCW) DIRECTION

Switch Closure:



Function:

If L51=0,2,4,6

Activating the CCW Direction input will start motion in the counterclockwise direction.

If L51=1,3,5,7

This signal is used as programmable input 6 for a G20 or G22 line command.

Notes:

Serial/Parallel must be active (Parallel mode).

If any motion other than CCW manual motion is active or if a Program Cycle is active, the CCW Direction input will not be honored.

The following chart lists the action which will occur with each possible combination of inputs that affect CCW operation.

INPUTS THAT AFFECT CCW OPERATION			
CCW INPUT	STEP/JOG INPUT	LOW/HIGH INPUT	FUNCTION
active	active	active	Ramp to Jog Speed rate and Jog
active	active	inactive	Jog at <i>Low Speed</i> rate
active	inactive	active	Ramp to Jog Speed rate and Step
active	inactive	inactive	Step at <i>Low Speed</i> rate
active	active or inactive	inactive to active	Ramp to Jog Speed rate
active	active or inactive	active to inactive	Ramp to <i>Low Speed</i> rate

Related Inputs:

Step/Jog
Low/High

Counterclockwise (CCW) Limit

Switch Closure:



Function:

If L45=0

The CCW Limit input is used to indicate the end of the allowable travel in the CCW direction.

If L45=1

This signal is used as programmable input 4 for a G20 or G22 line command.

Notes:

The CCW Limit is usually activated by a switch that closes when the system reaches the end of permissible travel in the CCW direction.

During motion, the indexer tests this input for the switch closure. If the switch closure occurs, any motion that is taking place in the CCW direction will come to an uncontrolled stop. **When this happens, it may result in an inaccurate absolute position count.**

When the CCW Limit input is activated during an *index* cycle, the *index* will be terminated.

Motion will only be allowed in the CW direction as long as the CCW Limit input remains active.

Cycle Start

Switch Closure:



Function:

The Cycle Start input is used to initiate program execution.

Notes:

When this input is activated, the Indexer will start execution of the program starting from the current line number.

If the Indexer is in the Single Line Execution mode (L06 1), the current line will be executed once.


If the Indexer is in the Automatic Execution mode (L06 2), the program will be executed once plus the number of times entered for the Repeat Count (L47) value.

Activating the Cycle Start while in the Continuous Execution mode (L06 3) causes the program to execute continuously.

When the Continuous Execution mode is selected, the Repeat Count value is ignored.

Feed Hold

Switch Closure:



Function:

Activating the Feed Hold will cause any motion that is occurring to come to a controlled stop. The absolute position count will remain accurate.

Notes:

The rate at which the motor will decelerate to a stop when Feed Hold is activated is determined by the value in the Accel/Decel register.

To continue a motion cycle that was occurring when the Feed Hold input was activated, simply reactivate the input that started that cycle.

If you want to terminate the motion cycle that was occurring, activate the Clear input. If the Clear input is used in this instance, the absolute position count will remain accurate.

Home Limit/Index From Run

Switch Closure:



Function:


The Home Limit/Index From Run input is used to indicate the *mechanical home* position when a Return To *Mechanical Home* cycle is active, or to indicate the *index* starting point when an *Index From Run* cycle is active.

Notes:

This input is tested for a switch closure only when the Indexer is performing a Return To *Mechanical Home* cycle or an *Index From Run* cycle. It is ignored in all other cycles.

Input 1

Switch Closure:



Function:

This signal is used as programmable input 1 for line execution of a G20 or a G22 command.

Notes:

During program execution, the Indexer tests this input for a switch closure and compares it with the input 1 condition for a G20 or G22 command.

Input 2

Switch Closure:



Function:


This signal is used as programmable input 2 for line execution of a G20 or a G22 command.

Notes:

During program execution, the Indexer tests this input for a switch closure and compares it with the input 2 condition for a G20 or G22 command.

Load

Switch Closure:



Function:

Activating the Load input will cause the Indexer to load the information which has been entered on the Strobe 2 through Strobe 7 inputs. It is used to load data into the register which has been selected using the Select 1, Select 2 and Select 4 inputs (reference Register Selection Chart Section 5.1).

Notes:

Serial/Parallel must be active (Parallel mode).

To load data into the indexer, first select the desired register by activating the correct combination of Select inputs as noted in the Register Selection Chart in Section 5.1. Then select the information to be entered into the register by activating the correct combination of the Code 1 through Code 400 and the Data 1 through Data 80M inputs. Finally, activate the Load input to enter the data.

When the indexer recognizes the Load input, $\overline{\text{Strobes 0}}$ and $\overline{\text{T}}$ are disabled. $\overline{\text{Strobes 2}}$ through $\overline{\text{7}}$ are then activated, in sequence. Once the data has been strobed into the register, the Indexer will reactivate $\overline{\text{Strobes 0}}$ through $\overline{\text{T}}$.

Example:

To load a move of +98,395 into the X register, first select the correct register by activating the Select 2 input (see chart, Section 5.1). The Select 1 and Select 4 inputs should remain inactive.

Next, select the desired data for that register by activating the Data 80K, Data 10K, Data 8K, Data 200, Data 100, Data 80, Data 10, Data 4 and Data 1 inputs.

Finally, activate the Load input. The indexer will deactivate $\overline{\text{Strobes 0}}$ and $\overline{\text{T}}$ and will activate $\overline{\text{Strobes 2}}$ through $\overline{\text{7}}$ to strobe the data into the register.

Following the strobing of the data into the register, the indexer will reactivate $\overline{\text{Strobes 0}}$ and $\overline{\text{T}}$.

Refer to the Strobe Timing Diagrams in Figure 5.3 for additional information on the load sequence.

Related Inputs:

Sign & Data 1 through Data 80M
Code 1 through Code 400
Select inputs
Serial/Parallel input

Low/High

Switch Closure:



Function:

The Low/High input is used to select the speed at which motion will take place.

Notes:

When the Low/High input is inactive, any motion that occurs will take place at the rate programmed in the *Low Speed* register.

If the Low/High input is active, the motor will ramp from the *Low Speed* rate up to the rate programmed for that motion cycle.


When motion is taking place and the Low/High input is changed from active to inactive, the motor will ramp down to the rate programmed in the *Low Speed* register. If either step or jog motion is occurring and the Low/High input is changed from inactive to active, the motor will ramp up to the rate programmed for that motion cycle.

The following chart further explains the type of motion that will occur for various conditions.

SPEEDS AT WHICH MOTION WILL OCCUR		
Type of Motion Selected	LOW/HIGH INPUT STATUS	
	ACTIVE	INACTIVE
Manual Jog	Jog Speed	<i>Low Speed</i>
Manual Step	Jog Speed	<i>Low Speed</i>
<i>Index</i>	Feed Rate	<i>Low Speed</i>
<i>Backlash</i>	Feed Rate	<i>Low Speed</i>
Auto Reverse	Feed Rate	<i>Low Speed</i>
Return to <i>Electrical Home</i>	Home Speed	<i>Low Speed</i>
Return to <i>Mechanical Home</i>	Home Speed	<i>Low Speed</i>
<i>Index</i> to Home Limit Input	Home Speed	<i>Low Speed</i>
Find Home Limit Input	Low Speed	<i>Low Speed</i>
Step Off Home Limit Input	Low Speed	<i>Low Speed</i>
Back Up to Home Limit Input	Low Speed	<i>Low Speed</i>
<i>Mechanical Home</i> Offset Move	Home Speed	<i>Low Speed</i>

Serial/Parallel

Switch Closure:



Function:

This input selects the RS232 port (input inactive) or the Parallel port (input active) for data entry or motion control.

Notes:

Serial Mode:

Manual Jog and Step functions are ignored (CW DIR, CCW DIR and STEP/JOG).

The Register Select and Load inputs are ignored (SEL 1, SEL 2, SEL 4 and LOAD).

All other parallel commands are honored.

Parallel Mode:

RS232 Manual Motion and Program Execution commands are ignored (H1, H2, H3, H6, H7, H8, H9, H10, H30).

Program Line Data and certain parameters cannot be altered (Nnnn, Gnn, Xsnnnnnnnn, Fnnnnnn, H11, H12, H14, L06, L07, L08, L09, L11, L12, L13, L14, L17, L18, L19, L20, L21, L22, L23, L25, L26, L41, L43, L44, L45, L47, L48, L51, L66, L67, L70, L71, L72, L73, L95).

Mode changes are not allowed (H33, H34, H35, H36, H37, H38, H39, H40).

All other RS232 commands are allowed.

Step/Jog

Switch Closure:



Function:

If L51 = 0, 2, 4 or 6

The Step/Jog input selects the type of motion that will be performed.

If L51 = 1, 3, 5 or 7:

This signal is used as programmable input 7 for Line Execution of a G20 or G22.

Notes:

L51 = 0, 2, 4 or 6:

Serial/Parallel must be active (Parallel mode).

When this input is active, the motor will Jog in the desired direction whenever the CW DIR or the CCW DIR input is active.


When this input is inactive and the CW DIR or CCW DIR input is activated, the motor will Step in the desired direction.

L51 = 1, 3, 5 or 7:

During program execution, the Indexer tests this input for a switch closure and compares it with the input 7 condition for a G20 or G22 command.

Stop Cycle

Switch Closure:



Function:

When this input is activated, program execution will be stopped.

Notes:

Any motion that is taking place when the Stop Cycle input is activated will be allowed to finish, but a new motion will not be allowed to start.

5.3 LOAD CYCLE INPUT SIGNALS

Code Inputs

Switch Closure:

Refer to Figure 5.1 for appropriate connection for each input (Code 800, Code 400, Code 200, Code 100, Code 80, Code 40, Code 20, Code 10, Code 8, Code 4, Code 2, Code 1).

Function:

These inputs are used to select the required numerical data for a Line Number, L code, G code or H code.

Refer to Section 5.2 for a complete description of how the Code inputs are used.

Data Inputs

Switch Closure:

Refer to Figure 5.1 for appropriate connection for each input (Data 80M, Data 40M, Data 20M, Data 10M, Data 8M, Data 4M, Data 2M, Data 1M, Data 800K, Data 400K, Data 200K, Data 100K, Data 80K, Data 40K, Data 20K, Data 10K, Data 8K, Data 4K, Data 2K, Data 1K, Data 800, Data 400, Data 200, Data 100, Data 80, Data 40, Data 20, Data 10, Data 8, Data 4, Data 2, Data 1).

Function:

The Data inputs are used to select the numerical data to be loaded into each register.

SEL 1, SEL 2, SEL 4

Switch Closure:

Refer to Figure 5.1 for appropriate connection for each input (SEL 4, SEL 2, SEL 1).

Function:

The Select inputs (SEL 1, SEL 2, SEL 4) are used to select the register which is to be loaded.

Notes:

Refer to the Register Selection Chart in Section 5.1 for additional information on the use of the Select inputs.

+ Sign/- Sign

Switch Closure:



Function:

This input is used to specify direction when loading information into a register.

Notes:

The input should be active if motion in the minus (CCW) direction is required and inactive if motion is to be in the plus (CW) direction.

5.4 PROGRAMMABLE REGISTERS

Line Number Loading

Function:	This value sets the current line number.
Units:	none
Range:	0 through 400
Default:	none
Load Sequence:	SEL 1 input to inactive SEL 2 input to inactive SEL 4 input to inactive Select the desired Code Data value (line number) Activate the Load input
Notes:	The Serial/Parallel input must be active (Parallel mode selected). This value will transfer the Strobed Code Data value to the current line number if the Code Data is in range. If the Code Data value is out of range, the previous line number will be retained.
Related inputs:	Serial/Parallel
Example:	Setting the current line number to 2 SEL 1 input to inactive SEL 2 input to inactive SEL 4 input to inactive Set Code Data inputs Code 2 active Code 1, Code 4, Code 8, Code 10, Code 20, Code 40, Code 80, Code 100, Code 200, Code 400 and Code 800 inactive Activate Load input

G Codes

Function:	Loads the G code register specified by the current line number.
Units:	none
Range:	See APPENDIX E for listing of G Codes.
Default:	none
Load Sequence:	SEL 1 input to active SEL 2 input to inactive SEL 3 input to inactive Select the Code Data value (G code) Activate the Load input
Notes:	<p>If the Code Data value is not a valid G code, the previous G Code Data will be retained.</p> <p>During program execution, the G code is tested to see if additional data fields are required. If the additional fields are in range, the G code command will be executed. If the additional fields are out of range, the program will be terminated and the line designated by the L41 command will become the current line.</p> <p>The Serial/Parallel input must be active (Parallel mode active)</p>
Related Inputs:	Serial/Parallel
Example:	Loading a G04 on the current line. SEL 1 input to active SEL 2 input to inactive SEL 4 input to inactive Set Code Data inputs Code 4 active Code 1, Code 2, Code 8, Code 10, Code 20, Code 40, Code 80, Code 100, Code 200, Code 400 and Code 800 inactive Activate Load input

X Code

Function:	This is used to specify the move distance and direction. It transfers the Sign and Field Data value to the X register specified by the current line number.
Units:	steps G code field data
Default:	none
Load Sequence:	SEL 1 input to inactive SEL 2 input to active SEL 4 input to inactive Select the sign and the Field Data values Activate the Load input
Notes:	<p>The Serial/Parallel input must be active (Parallel mode selected).</p> <p>During program execution, the X register value may be treated as a move or as an extension of a G code.</p> <p>When it is a move value, the Indexer will <i>index</i> the direction and distance programmed in this register. When the Incremental mode has been selected, the direction and distance will be relative to the position at the start of the motion. If the Indexer is in the Absolute mode, the direction and distance are relative to the <i>Electrical Home</i> position.</p> <p>When the Auto Reverse feature has been selected, the Indexer will automatically reverse at the end of the motion and will then <i>index</i> the distance programmed in this register.</p> <p>If L51 = 4 to 7, this function cannot be achieved.</p>

F Code

Function:

This value is used to specify the Feed Rate or G code field data.

During Program Execution, the F register value may be treated as a High Speed value or as an extension of a G code.

Units:

steps per second or
G code field data

Range:

Full Step Mode	0 to 115,000 steps per second
Half Step Mode	0 to 115,000 steps per second
1/5 Step Mode	0 to 115,000 steps per second
1/10 Step Mode	0 to 115,000 steps per second
1/125 Step Mode	0 to 1,875,000 steps per second

Default:

none

Load Sequence:

SEL 1 input to active
SEL 2 input to active
SEL 4 input to inactive
Select the Field Data value (F value)
Activate the Load input

Notes:

The field data value will be loaded into the F register for the current line number. If the data value is out of range, the previously loaded data will be retained.

If the value in the Feed Rate register is equal to or less than the *Low Speed* rate, the Feed Rate register will be used as the *Low Speed* rate during an index.

If the value in the *Low Speed* register is zero, the Indexer will ramp from standstill directly up to the Feed Rate register value at the start of motion and from this value directly down to zero at the end of the motion.

The value in the Feed Rate register is ignored when the Indexer is in the Low Speed mode.

If the data exceeds the rate programmed in the Ramp Limit register, the Ramp Limit register value will be used as the default value.

If L51 = 4 to 7, this function cannot be achieved.

Related Inputs:

Low/High

Related L Codes:

Low Speed (L12)
Ramp Frequency Limit (L71)

L Codes

Function:	Loads the selected L code register (code data) with the field data.
Units:	none
Range:	See APPENDIX A for listing of L Codes.
Default:	none
Notes:	The Serial/Parallel input must be active (Parallel mode selected). A L51 value of 0, 1, 2 or 3 must be programmed to enable this function.
Load Sequence:	SEL 1 input to inactive SEL 2 input to inactive SEL 4 input to active Select the Code Data for the desired L Code Select the Field Data for the desired L code Activate the Load input
Example:	Setting L71 = 10000 SEL 1 input to inactive SEL 2 input to inactive SEL 4 input to active Set Code Data inputs Code 1, Code 10, Code 20 and Code 40 active Code 2, Code 4, Code 8, Code 80, Code 100, Code 200, Code 400, Code 800 inactive Set Field Data inputs Data 10K active Data 1, Data 2, Data 4, Data 8, Data 10, Data 20, Data 40, Data 80, Data 100, Data 200, Data 400, Data 800, Data 1K, Data 2K, Data 4K, Data 8K, Data 20K, Data 40K, Data 80K, Data 100K, Data 200K, Data 400K, Data 800K, Data 1M, Data 2M, Data 4M, Data 8M, Data 10M, Data 20M, Data 40M and Data 80M inactive Activate Load input

H Codes

Function:	Executes the Designated H Code Command.
Units:	none
Range:	See APPENDIX B for listing of H Codes.
Default:	none
Load Sequence:	SEL 1 input to active SEL 2 input to inactive SEL 4 input to active Select the desired H code (Code data) Activate the Load input
Notes:	<p>The Serial/Parallel input must be active (Parallel mode selected)</p> <p>If the Code Data matches the one of the H codes, that H code will be executed if no motion is taking place.</p> <p>H6, H7, H31, H32 cannot be executed while in Parallel mode.</p> <p>Refer to Section 6.2, H Code Descriptions, for further information on specific H codes.</p>
Related Inputs:	Serial/Parallel
Example:	Starting an <i>Index From Run Cycle</i> (H30) using the values from the current line. SEL 1 input to active SEL 2 input to inactive SEL 4 input to active Set Code inputs Code 10 and Code 20 active Code 1, Code 2, Code 4, Code 8, Code 40, Code 80, Code 100, Code 200, Code 400 and Code 800 inactive Activate Load input

Initialization

Function: Initializes the Indexer to the *default* values of the selected resolution. Also clears all program lines (0 through 400).

Units: none

Default: none

Notes: The Serial/Parallel input must be active (Parallel mode selected).

If a Field Data value other than 1, 2, 5, 10 or 125 is selected, the full step *default* values will be set.

Example 1:

Setting the Indexer to Full Step *default* values

SEL 1 input to inactive

SEL 2 input to active

SEL 4 input to active

Set Code Data values

Code 1, Code 8, Code 10 and Code 80 active

Code 2, Code 4, Code 20, Code 40, Code 100, Code 200,

Code 400 and Code 800 active

Set Field Data inputs

Data 1 active

Data 2, Data 4, Data 8, Data 10, Data 20, Data 40, Data 80,

Data 100, Data 200, Data 400, Data 800, Data 1K, Data 2K, Data 4K,

Data 8K, Data 10K, Data 20K, Data 40K, Data 80K, Data 100K,

Data 200K, Data 400K, Data 800K, Data 1M, Data 2M, Data 4M,

Data 8M, Data 10M, Data 20M, Data 40M and Data 80M inactive

Activate Load input

Example 2:

Setting Indexer to Half Step *default* values

SEL 1 input to inactive

SEL 2 input to active

SEL 4 input to active

Set Code Data inputs

Code 1, Code 8, Code 10 and Code 80 active

Code 2, Code 4, Code 20, Code 40, Code 100, Code 200,

Code 400 and Code 800 inactive

Set Field Data inputs

Data 2 active

Data 1, Data 4, Data 8, Data 10, Data 20, Data 40, Data 80,

Data 100, Data 200, Data 400, Data 800, Data 1K, Data 2K, Data 4K,

Data 8K, Data 10K, Data 20K, Data 40K, Data 80K, Data 100K,

Data 200K, Data 200K, Data 400K, Data 800K, Data 1M, Data 2M,

Data 4M, Data 8M, Data 10M, Data 20M, Data 40M and Data 80M

inactive

Activate Load input

Initialization examples continued

Example 3:

Setting Indexer to 1/5 step *default* values

SEL 1 input to inactive

SEL 2 input to active

SEL 4 input to active

Set Code Data inputs

Code 1, Code 8, Code 10 and Code 80 active

Code 2, Code 4, Code 20, Code 40, Code 100, Code 200,

Code 400 and Code 800 inactive

Set Field Data inputs

Data 1 and Data 4 active

Data 2, Data 8, Data 10, Data 20, Data 40, Data 80, Data 100,

Data 200, Data 400, Data 800, Data 1K, Data 2K, Data 4K, Data 8K,

Data 10K, Data 20K, Data 40K, Data 80K, Data 100K, Data 200K,

Data 400K, Data 800K, Data 1M, Data 2M, Data 4M, Data 8M,

Data 10M, Data 20M, Data 40M and Data 80M inactive

Activate Load input

Example 4:

Setting Indexer to 1/10 step *default* values

SEL 1 input to inactive

SEL 2 input to active

SEL 4 input to active

Set Code Data inputs

Code 1, Code 8, Code 10 and Code 80 active

Code 2, Code 4, Code 20, Code 40, Code 100, Code 200,

Code 400 and Code 800 inactive

Set Field Data inputs

Data 10 active

Data 1, Data 2, Data 4, Data 8, Data 20, Data 40, Data 80, Data 100,

Data 200, Data 400, Data 800, Data 1K, Data 2K, Data 4K, Data 8K,

Data 10K, Data 20K, Data 40K, Data 80K, Data 100K, Data 200K,

Data 400K, Data 800K, Data 1M, Data 2M, Data 4M, Data 8M,

Data 10M, Data 20M, Data 40M and Data 80M inactive.

Activate Load input

Example 5:

Setting Indexer to 1/125 step *default* values

SEL 1 input to inactive

SEL 2 input to active

SEL 4 input to active

Set Code Data inputs

Code 1, Code 8, Code 10 and Code 80 active

Code 2, Code 4, Code 20, Code 40, Code 100, Code 200,

Code 400 and Code 800 inactive

Set Field Data inputs

Data 1, Data 4, Data 20 and Data 100 active

Data 2, Data 8, Data 10, Data 40, Data 80, Data 200, Data 400,

Data 800, Data 1K, Data 2K, Data 4K, Data 8K, Data 10K, Data 20K,

Data 40K, Data 80K, Data 100K, Data 200K, Data 400K, Data 800K,

Data 1M, Data 2M, Data 4M, Data 8M, Data 10M, Data 20M,

Data 40M and Data 80M inactive

Activate Load input

SECTION 6: RS232 COMMANDS

6.0 General Programming Information

EIA (Electronic Industries Association) Standard RS274-D, the programming guide for numerically controlled machines, has been used as the basis for the Micro Series Indexer command structure. Although it was not technically feasible to conform to this standard in complete detail, it proved beneficial in the program structure to permit complex and varied operations to be performed using a simple format. The RS232 parameters and commands can be grouped into three general categories:

1. **"L Codes"** (described in Section 6.1) are used to set parameters for each Indexer. These commands do not cause motion, but simply establish the motion parameters.
2. **"H Codes"** (described in Section 6.2) are used to set Indexer modes, to control manual and program execution and to transmit parameters and Indexer status via the serial communications port.
3. **Line Data Codes** (described in Section 6.3), are the codes that define the motion that will be made (X Code), the speed at which it will be done (F Code) and G Code which can control program execution and modify the way it operates.

Buffering Of Commands

A Micro Series Programmable Indexer has two buffers dedicated to RS232 communications. Each buffer holds 255 characters. One buffer holds commands which will be processed only when the Indexer is not "Busy" (when a cycle is in process or when previously transmitted commands are being processed). These commands are referred to as "Standard" commands and include all L codes, H codes and Line Data codes. They are processed in the order in which they are received, and each command must be completed before the next command is processed.

The second buffer holds commands which will be processed as soon as they are issued, even when the Indexer is "Busy". These commands are known as "Immediate" commands and include only a subset of the L codes, H codes and Line Data codes. To indicate that a command should be treated as an immediate command, simply precede the command with an exclamation mark (!). A list of immediate commands is given in Appendix C. Immediate commands are processed in the order in which they are received, as are standard commands.

Multiple commands can be transmitted to the Indexer at the same time. The Carriage Return (ASCII 13) and/or Line Feed (ASCII 10) will terminate a string of commands. If a string of immediate commands is to be sent, the "!" character need only be used in front of the first command. The Immediate Buffer selection is canceled when the Carriage Return or Line Feed is received.

The "Backspace And Delete" command, Control H (^H) can be used to delete a character in a buffer when data is being entered. In addition, the "Delete RS232 Buffer" command, Control X (^X), can be used to delete the last line entered in the active buffer.

The number of characters remaining in either the standard or the immediate character buffer may be requested at any time. To request the status of the standard buffer, send the "/" character (ASCII 47). Send the "\" character (ASCII 92) to request the status of the immediate buffer. Neither character is actually stored in the buffer. The response format from the Indexer is:

nnn CRLF

where nnn is the character count remaining.

Xon/Xoff Protocol

Xon/Xoff is a serial communications protocol, executed in software, that allows communications between two devices without the need for additional hardware control. This method of controlling data flow requires only a three-wire connection between the devices. The protocol is used for controlling the flow of data between the Indexer and another device. **It should NOT be used to determine the status of the Indexer.**

The Xoff character (ASCII 19) is used to stop the transmission of RS232 characters. When one device sends an Xoff to the other device, it is telling the other to stop transmitting characters. The transmitting device should comply with the request.

The Xon character (ASCII 17) is used to resume transmission of the RS232 characters. When one device sends an Xon character to the other, it is signifying that it is ready to receive more data. If there is more data to be sent, the transmitting device may now resume transmission.

When the Indexer sends an Xoff command to the host, all activation commands (see below) and immediate H codes can still be processed.

Note: The Xon/Xoff protocol is only used when the L26 value is 0-3.

Device Identification

In order to daisy chain multiple Indexers to communicate with a single host, each Indexer must be given a unique identification. The L21 value defines the identification number of the Indexer. **Each Indexer must be given a unique identification before the system is wired.** The device addresses need not be consecutive, and the Indexers can be placed in any positions in the chain regardless of their addresses.

Refer to the *Baud Rate* chart in Section 3.2 for information concerning the maximum baud rate which can be achieved for a given number of Indexers in a system.

Device Activation

In order to accept commands from a host device, an Indexer must be set to the active mode. To do this, the host must send the device attention command (<) followed by the device identification number and, as always, a carriage return/line feed. For example, to activate device 01 send <01CRLF. The Indexer which has been activated will respond with an = if it is not busy, or with a : if it is busy. If you wish the Indexer to identify itself in the response, include a ? in the request (<01?CRLF). The response will be 01= if the Indexer is not busy, or 01: if it is busy.

Note: If L26= 0 thru 3, an Xon will be transmitted following the =. If L26= 4 thru 7, no Xon will be transmitted.

All Indexers can be activated at the same time by issuing a <00CRLF from the host. Any information requested from the Indexers while all units are active will cause all Indexers to transmit at once, resulting in garbled data. Therefore, transfer commands should be avoided and any characters received by the host should be ignored when all Indexers are active.

If the host wishes to identify the active Indexer, the Device Acknowledgement command (?) can be issued. If the active device is not busy, it will respond with a nn=Xon, where nn is the device ID. If the active device is busy, it will respond with a nn:. If no device is active, no response will be received. (Xon will not be transmitted if the protocol is disabled.)

Refer to Figure 6.1 for a Communications flowchart.


Listen Mode

In addition to the active mode, an Indexer can also be placed in the listen mode. To do this, the host must send the device attention command (<), followed by the device identification number, followed by an ampersand (&). For example, to place device 01 in the listen mode, send <01&CRLF. In response to the listen command, the Indexer will send a 01=Xon if it is not busy, or a 01: if it is busy. (Again, Xon will not be transmitted if the protocol is disabled.)

While in the listen mode, an Indexer will execute commands issued by the host. However, it will transfer data only in response to its device attention command for busy polling. All other transfer commands will be ignored while in the listen mode.

To cancel the listen mode, the host must transmit the device attention command (<), followed by the device attention character, followed by an @. For example, to cancel the listen mode for device 01, send <01@. This device will now become the active device.

All Indexers can be placed in the listen mode by issuing a <00&CRLF from the host. To cancel this mode for all Indexers, a <00@ can be sent from the host. When this is done, all Indexers become active.



NOTES: "Busy" means that the Indexer cannot accept or process any new commands via RS232 because a program is executing and/or motion is occurring.

"Ready" means that motion has ceased and/or program execution is completed. The Indexer can now accept further information.

Immediate commands can be processed anytime.

Figure 6.1, PC Program Flow Chart For Indexer Communications

General Programming Comments

1. The first task that faces an operator is that of setting "L codes", the parameters of each indexer.
2. It is important to note the **factory default values** that have been set for each parameter. These default values allow entry steps to be eliminated for those parameters where the factory default value is acceptable.
3. If invalid data is entered for any parameter or field, the previous data will not be replaced.
4. If the number of characters entered for a parameter exceeds the number of characters required, the data is truncated to the correct length by eliminating the first characters sent. For example, if a parameter requires eight characters and ten are sent, only the last eight will be used.
5. In the command descriptions which follow, the field descriptions for each command use an "n" to designate a number and an "s" to designate a sign (+ or -). For example, the field designation "snnnnnnnn" designates that the field consists of a + or - sign followed by eight numbers
6. Some functions which can be executed through the parallel port may be activated at any time. This allows the user to perform system set up through RS232 and operation through the parallel port. Refer to Section 5.2 Serial/Parallel for the restrictions. Note that if a parameter is changed over the serial port, it will override the switch setting on the panel. For example, if the High Speed is selected on the panel and then the RS232 command for Low Speed mode is sent followed by a request for a CCW move from the panel, the move will be executed at Low Speed even though the panel switch is set at the High Speed mode.

7. Note that defaults which are dependent on the L70 value are set when the L70 is programmed at the factory. If the L70 value is changed, these values will not change automatically.
8. When using any of the L, H and G codes, preceding zeros can be omitted. For example, H1CRLF will perform the same as H01CRLF.
9. If it is necessary to know when an *index* motion is complete, the Line Done Character (L55) parameter can be used. Note that if a Program Line Delay is programmed, the character will not be transmitted until the delay has expired. The Immediate Transfer Mode Status (!H19) can also be monitored. The second most significant character will be set (1) if motion is active and Clear (0) if motion is inactive.
10. Appendix I shows how to develop the Indexer program for a typical application.

6.1 L CODE DESCRIPTIONS

L06 Execution Format

Function:	The L06 Code is used to define the way in which the program executes.
Units:	none
Range:	1 = Single-Line Execution 2 = Automatic Program Execution 3 = Continuous Program Execution
Default:	2 = Automatic Program Execution
Command Format:	L06 nCRLF
Notes:	<p>In the Single-Line Execution mode (1), the line will be executed once when a Cycle Start command is given.</p> <p>In the Automatic Execution mode (2), the program will be executed once plus the number of times programmed in the Repeat Count register.</p> <p>In the Continuous Execution mode (3), the program will be executed continuously.</p> <p>The Repeat Count register value will be ignored if the Indexer is in the Single Cycle or the Continuous Cycle mode.</p>
Related RS232 Commands:	"H1" (Cycle Start) start program execution "\$" (Feed Hold) pause motion "**" (Clear) uncontrolled motion stop or cancel program execution "#" (Program Stop) stop program after current line is executed

L07 Strobe Delay

Function:	This code is used to define the active low time of the Strobe 2 through 7 outputs. Each Strobe output will be active for the selected time as the Strobes are activated in succession.
Units:	milliseconds
Range:	0 to 9,999
Default:	0
Command format:	L07 nnnnCRLF
Example:	L07 1000 CRLF sets the strobe delay to 1000 milliseconds.

L08 Mechanical Home Direction

Function:	This code defines the direction to be used when a Return to <i>Mechanical Home</i> command is issued.
Units:	none
Range:	+ (CW direction) - (CCW direction)
Default:	+ (CW direction)
Command format:	L08 sCRLF
Related RS232 commands:	"H10" (Return To <i>Mechanical Home</i> Start). "\$" (Feed Hold) pause motion "**" (Clear) uncontrolled motion stop
Related G Code command:	"G78" (Program line Return to <i>Mechanical Home</i>)
Example:	L08 + CRLF sets a clockwise <i>Mechanical Home</i> direction.

L09 Jog Speed

Function:	The L09 command defines the speed to be used when the Indexer is in the High Speed mode and a Jog or a Step command is given.
Units:	pulses per second
Range:	1 to 115,000 for L70=1 1 to 115,000 for L70=2 1 to 115,000 for L70=5 1 to 115,000 for L70=10 1 to 1,875,000 for L70=125
Default:	1,000 for L70=1 2,000 for L70=2 5,000 for L70=5 10,000 for L70=10 125,000 for L70=125
Command format:	L09 nnnnnnnCRLF
Notes:	<p>If the selected Jog Speed is equal to or less than the <i>Low Speed</i> rate, the Jog Speed rate will be used as the <i>Low Speed</i> rate during a manual jog.</p> <p>If the <i>Low Speed</i> rate is zero, the Indexer will ramp from standstill directly up to the Jog Speed rate at the start of motion and from the Jog Speed rate directly down to standstill at the end of the motion.</p> <p>The Jog Speed rate is ignored if the Indexer is in the <i>Low Speed</i> mode.</p> <p>The Ramp Frequency Limit (L71) value determines the maximum <i>High Speed</i> which will be allowed.</p>
Related RS232 Commands:	H02 (Select Step Mode) H03 (Select Jog Mode) H04 (Select High Speed Mode) H05 (Select Low Speed Mode) H06 (Start CW Motion) H07 (Start CCW Motion) \$ (Feed Hold) pause motion * (Clear) uncontrolled motion stop
Related L Codes:	L11 (Accel/Decel) L12 (<i>Low Speed</i>)
Example:	L09 2000CRLF sets the Jog <i>High Speed</i> to 2000 pulses per second.

L11 Acceleration/Deceleration

Function:	This command defines the maximum acceleration/deceleration value allowed for the selected ramp profile (L72).
Units:	pulses per second ²
Range:	1 to 99,999,999
Default:	1,000 for L70 = 1 2,000 for L70 = 2 5,000 for L70 = 5 10,000 for L70 = 10 125,000 for L70 = 125
Command Format:	L11 nnnnnnnCRLF
Notes:	<p>When motion begins, the Indexer will go directly from standstill to the <i>Low Speed</i> rate without acceleration and will then ramp up to the appropriate speed rate at the acceleration rate programmed for this parameter.</p> <p>At the end of the motion, the Indexer will ramp down to the <i>Low Speed</i> rate at the deceleration value programmed in this register and will then stop.</p>
Related L Codes:	L72 (Ramp Profile Select)
Example:	L11 2000 CRLF sets the acceleration/deceleration rate to 2,000 pulses per second ² .

L12 Low Speed

Function:	The L12 command defines the speed to be used as the <i>Low Speed</i> rate when the Indexer is in the <i>Low Speed</i> mode. This rate is also used as the instantaneous starting rate when the Indexer is in the <i>High Speed</i> mode.
Units:	pulses per second
Range:	0 to 115,000 for L70=1 0 to 115,000 for L70=2 0 to 115,000 for L70=5 0 to 115,000 for L70=10 0 to 1,875,000 for L70=125
Default:	300 for L70=1 600 for L70=2 1,500 for L70=5 3,000 for L70=10 37,500 for L70=125
Command Format:	L12 nnnnnnn CRLF
Notes:	<p>When motion begins, the Indexer will go directly from standstill to the <i>Low Speed</i> rate without acceleration. At the end of the motion, the Indexer will go directly from the <i>Low Speed</i> rate to standstill without deceleration.</p> <p>When <i>Low Speed</i> operation has been selected, motion is performed at the Low Speed rate and all other programmed speeds are ignored.</p> <p>If the <i>Low Speed</i> rate has been selected and the programmed <i>Low Speed</i> rate is zero, no motion will occur and the motion command will be terminated.</p> <p>If the <i>High Speed</i> rate has been selected and the programmed speed rate is equal to or less than the <i>Low Speed</i> rate, the programmed speed will be used as the <i>Low Speed</i> rate. If the <i>High Speed</i> has been selected and the programmed <i>Low Speed</i> rate is zero, the Indexer will ramp from standstill up to the programmed speed at the start of motion and from the programmed speed down to standstill at the end of the motion.</p> <p>The Ramp Frequency Limit (L71) value sets the maximum <i>High Speed</i> allowed.</p>
Related L Codes:	L09 (Jog Speed) L11 (Accel/Decel) L14 (Home Speed) L71 (Ramp Frequency Limit)
Related RS232 Commands:	H2 (Select <i>Step Mode</i>) H3 (Select <i>Jog Mode</i>) H4 (<i>High Speed Mode</i>) H5 (<i>Low Speed Mode</i>) H6 (Start CW Motion) H7 (Start CCW Motion) \$ (Feed Hold) pause motion * (Clear) uncontrolled motion stop
Example:	L12 320 CRLF sets the <i>Low Speed</i> value to 320 pulses per second.

L13 Step Increment

Function:	The L13 parameter defines the number of steps to be indexed when the Indexer is in the <i>Step mode</i> and a CW or CCW command is given.
Units:	pulses
Range:	1 to 99,999,999
Default:	1 pulse for L70=1 2 pulses for L70=2 5 pulses for L70=5 10 pulses for L70=10 125 pulses for L70=125
Command Format:	L13 nnnnnnnn CRLF
Notes:	If the CW and/or CCW software limits are enabled and the move distance programmed here will cause a limit to be exceeded, the move will not be allowed.
Related RS232 Commands:	H02 (Select <i>Step Mode</i>) H03 (Select <i>Jog Mode</i>) H06 (Start CW Motion) H07 (Start CCW Motion) \$ (Feed Hold) pause motion * (Clear) uncontrolled motion stop
Example:	L13 200 CRLF sets the Step Size value at 200 pulses.

L14 Home Speed

Function:	The L14 parameter defines the value to be used as the step rate when the Indexer is in the <i>High Speed</i> mode and a Return To <i>Electrical Home</i> or a Return To <i>Mechanical Home</i> command is issued.
Units:	pulses per second
Range:	1 to 115,000 for L70=1 1 to 115,000 for L70=2 1 to 115,000 for L70=5 1 to 115,000 for L70=10 1 to 1,875,000 for L70=125
Default:	1,000 for L70=1 2,000 for L70=2 5,000 for L70=5 10,000 for L70=10 125,000 for L70=125
Command Format:	L14 nnnnnnn CRLF
Notes:	<p>If the Home Speed rate is equal to or less than the <i>Low Speed</i> rate, the Home Speed rate will be used as the <i>Low Speed</i> rate during a homing cycle.</p> <p>If the <i>Low Speed</i> rate is zero, the Indexer will ramp from standstill directly up to the Home Speed rate at the start of motion and will ramp from this rate directly down to standstill at the end of the motion.</p> <p>The Home Speed rate will be ignored if the Indexer is in the <i>Low Speed</i> mode.</p> <p>The Ramp Frequency Limit (L71) value sets the maximum speed that will be allowed.</p>
Related L Codes:	L12 (<i>Low Speed</i>)
Related RS232 Commands:	H04 (<i>High Speed Mode</i>) H05 (<i>Low Speed Mode</i>) H08 (Return To <i>Electrical Home</i>) H10 (Return To <i>Mechanical Home</i>) \$ (Feed Hold) pause motion * (Clear) uncontrolled motion stop
Related G Code commands:	G76 (Return To <i>Electrical Home</i>) G78 (Return To <i>Mechanical Home</i>)
Example:	L14 3000 CRLF sets the Home <i>High Speed</i> at 3000 pulses per second.

L16 Index From Run Travel Limit

Function:	This parameter defines the maximum <i>Index From Run</i> distance allowed before the cycle comes to a controlled stop.
Units:	pulses
Range:	0 to 99,999,999
Default:	0 (disabled)
Command Format:	L16 nnnnnnnn CRLF
Notes:	<p>If a value other than zero is placed in L16, this value will be the maximum number of pulses to be allowed during an <i>Index From Run</i> cycle. If this number is exceeded, motion will cease, the Position Error output will be activated and a status bit will be set in the Motion Error status.</p> <p>The L16 value should be slightly larger than the distance between the <i>Index</i> markers plus the <i>Index</i> move distance.</p>
Related RS232 Commands:	H30 (<i>Index From Run</i>) \$ (Feed Hold) Pause Motion * (Clear) Uncontrolled Motion Stop
Related G Code Command:	G10 (<i>Index From Run</i>)
Example:	L16 2000 CRLF sets the <i>Index From Run Travel Limit</i> at 2000 pulses.

L17 Offset From Mechanical Home

Function:	This parameter defines the offset distance and direction to be indexed once the Indexer has reached the Home Limit switch.
Units:	pulses
Range:	-99,999,999 to +99,999,999
Default:	+0
Command Format:	L17 snnnnnnnnCRLF
Notes:	<p>Once the Indexer has offset from the Home Limit switch, the new position will be established as <i>Electrical Home</i>.</p> <p>The Home Offset register value is only used during a Return To <i>Mechanical Home</i> cycle. It is not used during a Return To <i>Electrical Home</i> cycle.</p>
Related RS232 Commands:	H10 (Return To <i>Mechanical Home</i>) \$ (Feed Hold) pause motion * (Clear) uncontrolled motion stop
Related G Code Command:	G78 (Return To <i>Mechanical Home</i>)
Example:	L17 +1000 CRLF sets the <i>Electrical Home</i> Offset at +1000 pulses from Mechanical Home.

L18 Clockwise Software Travel Limit

Function:	This value represents the maximum distance that the Indexer will be allowed to travel in the CW direction.
Units:	pulses
Range:	+0 to +99,999,999 (-0 disables this function)
Default:	-0 (function disabled)
Command Format:	L18 snnnnnnnnCRLF
Notes:	<p>If the limit is exceeded during a Jog cycle, motion will come to a controlled stop. No further motion will be allowed in the CW direction until the Absolute Position count is less than the L18 value.</p> <p>The Indexer will not perform a clockwise <i>index</i> cycle (step or program execution) if the resulting position will be equal to or greater than the L18 value.</p>
Examples:	<p>L18 -0 CRLF disables the Clockwise Software Travel Limit.</p> <p>L18 +100000 CRLF enables the Clockwise Software Travel Limit and sets it at +100000 pulses.</p>

L19 Counterclockwise Software Travel Limit

Function:	This value represents the maximum distance that the Indexer will be allowed to travel in the CCW direction.
Units:	pulses
Range:	-0 to -99,999,999 (+0 disables this function)
Default:	+0 (function disabled)
Command Format:	L19 snnnnnnnnCRLF
Notes:	<p>If the limit is exceeded during a Jog cycle, motion will come to a controlled stop. No further motion will be allowed in the CCW direction until the Absolute Position count is less than the L19 value.</p> <p>The Indexer will not perform a counterclockwise <i>index</i> cycle (step or program execution) if the resulting position will be equal to or greater than the L19 value.</p>
Examples:	<p>L19 +0 CRLF disables the Counterclockwise Software Travel Limit.</p> <p>L19 -100000 CRLF enables the Counterclockwise Software Travel Limit and sets it at -100000 pulses.</p>

L20 Up/Down Feed Rate Override

Function:	Specifies how the Up (!H31) and Down (!H32) commands are treated when motion is completed.
Units:	none
Range:	0 Forget commanded Up/Down velocity after completing motion. 1 Remember the commanded Up/Down velocity if it occurs during <i>Index</i> motion. This velocity will be forgotten if a program line Feed Rate (Nnnn Fnnnnnn) or Feed Rate Override (!Fnnnnnn) is encountered.
Default:	none
Command Format:	L20 n CRLF
Notes:	This parameter relates to programmed moves only. If enabled this velocity becomes the programmed <i>index</i> move velocity and will be remembered even if the indexer is powered down.

L21 Device Identification Number

Function:	Defines the ID of the Indexer.
Units:	none
Range:	1 to 99
Default:	1
Command Format:	L21 nnCRLF
Notes:	When multiple indexers have been daisy chained, a unique ID must be assigned to each indexer. This ID number will be used with the "<nn" "Device Attention" command to activate a specific indexer.
Example:	L21 5 CRLF sets the Indexer ID to 5.

L22 Baud Rate

Function:	Sets the RS232 baud rate.
Units:	bits per second
Range:	300, 1200, 2400 or 9600
Default:	9600
Command Format:	L22 nnnnCRLF
Example:	L22 2400 CRLF sets the RS232 baud rate at 2400 bits per second.

L23 Character Length

Function:	Sets the number of data bits in each character sent via the RS232 serial port.
Units:	bits
Range:	7 or 8
Default:	8
Command Format:	L23 nCRLF
Example:	L23 7 CRLF sets the RS232 character length to 7 bits.

L25 RS232 Parity

Function:	Sets the parity protocol for characters sent via the RS232 serial port.
Units:	none
Range:	1 = parity disabled 2 = odd parity enabled 3 = even parity enabled
Default:	1 (parity disabled)
Command Format:	L25 nCRLF
Notes:	When parity is disabled, two stop bits will be sent regardless of the character length. If odd or even parity is selected, one stop bit will be sent if the L23 character length is 8 and two stop bits will be sent if the L23 character length is 7.
Example:	L25 3 CRLF sets the RS232 character parity to even.

L26 Command Acknowledgement

Function: Selects the transmission protocol the Indexer will use when responding to input commands.

Units: none

Range: 0 to 7 (see below)

Default: 0

Command Format: L26 n CRLF

Notes:

Xon/Xoff Protocol Enabled	
n=0	normal transmission mode (no "EOT" or "=" characters)
n=1	"EOT" follows each complete data transmission
n=2	"=" is transmitted when the indexer is ready for more commands
n=3	"EOT" follows each complete data transmission and "=" is transmitted when the indexer is ready for more commands
Xon/Xoff Protocol Disabled	
n=4	normal transmission mode (no "EOT" or "=" characters)
n=5	"EOT" follows each complete data transmission
n=6	"=" is transmitted when the indexer is ready for more commands
n=7	"EOT" follows each complete data transmission and "=" is transmitted when the indexer is ready for more commands

EOT: ASCII 04 decimal.

Examples:

Indexer with device ID1 and Parameter L26 set to 3.

```

Command: <01CRLF
Response: =Xon

Command: H15CRLF
Response: Xoff NnnnCRLF EOT Xon=

Command: H18H19CRLF
Response: Xoff nnnnnnnnCRLF EOT
         nnnnnnnnCRLF EOT Xon
  
```

L41 Auto Start Line Number

Function:	Selects the line number to which the program line pointer will automatically be set during any of the following conditions: Upon power up During invalid program execution Upon encountering an End Of Program command After a Clear command
Units:	none
Range:	0 to 400
Default:	1
Command Format:	L41 nnn CRLF
Example:	L41 100 CRLF sets the auto start line number to 100.

L43 Delay Between Index And Backlash

Function:	Selects the delay that will occur between an <i>index</i> motion and a <i>backlash</i> cycle.
Units:	milliseconds
Range:	0 to 9,999
Default:	50
Command Format:	L43 nnnn CRLF
Example:	L43 100 CRLF sets a delay of 100 milliseconds between an <i>index</i> and a <i>backlash</i> cycle.

L44 Program Line Delay

Function:	Selects the delay that will occur between line executions.
Units:	milliseconds
Range:	0 to 9,999
Default:	50
Command Format:	L44 nnnn CRLF
Notes:	The delay should be of sufficient length to allow the motor to settle before the next <i>index</i> begins. A delay is necessary whenever the Continuous Cycle mode is selected, the Auto Reverse feature is enabled or the Auto Repeat feature is used.
Example:	L44 100 CRLF selects a delay of 100 milliseconds between line executions.

L45 Limit Switch Enable

Function:	Permits the CW Limit and CCW Limit inputs to be used as limit switch inputs (0) or as additional Programmable inputs (1) for the Branch On Input (G20) and Wait For Input Condition commands (G22).
Units:	none
Range:	0 = Limit Switches Enabled 1 = Programmable Inputs Enabled
Default:	0
Command Format:	L45 n CRLF
Notes:	<p>If activated when used as a limit switch input, the CW Limit or CCW Limit input will terminate motion in the CW or CCW direction and will prevent further motion in that direction until the limit is inactive again. If a limit is activated during program execution, motion will come to an uncontrolled stop and program execution will be terminated.</p> <p>When used as additional programmable inputs, CW Limit functions as Input 3 and CCW Limit functions as Input 4 for the Branch On Input Condition (G20) and Wait For Input Condition (G22) commands.</p>
Example:	L45 1CRLF selects use of the Limit inputs as programmable inputs.

L47 Repeat Count

Function:	This parameter sets the number of times a program will be repeated when the Indexer is in the Auto Execution (L06 2) mode.
Units:	none
Range:	0 to 99,999,999
Default:	0
Command Format:	L47 nnnnnnnn CRLF !L47 nnnnnnnn CRLF
Notes:	<p>The number of program cycles that will be performed is the L47 value plus one.</p> <p>If the Repeat Count value is changed during execution, and the new value has already been exceeded, the cycle will be terminated. If the new value has not been reached, execution will continue until it is reached.</p> <p>The Repeat Count value is ignored when in the Continuous Execution mode (L06 3) or the Single Execution mode (L06 1).</p>
Example:	<p>L47 50CRLF sets the Repeat Count value at 50 when motion has stopped.</p> <p>!L47 30CRLF sets the repeat count to 30 during motion.</p>

L48 Program Line Count Designator

Function:	Selects the Line Count Designator in response to a Clear Program or a Transfer Program Lines command.
Units:	none
Range:	0 to 400
Default:	20
Command Format:	L48 nnnCRLF !L48 nnnCRLF
Notes:	<p>If the L48 value is 0, all lines will be cleared in response to a Clear Program Lines command (H12) and all lines will be transferred in response to a Transfer Program Lines command (H14).</p> <p>If the L48 value is 1 through 400, the Indexer will start at the current line and use the L48 value as a line count when responding to a Clear Program Lines or Transfer Program Lines command.</p>
Examples:	<p>L48 0 H14CRLF will cause all lines to be transferred.</p> <p>L48 0 H12CRLF will cause all lines to be cleared.</p>
Related RS232 Commands:	H12 (Clear Program Lines using L48) H14 (Transfer Program Lines using L48)

L49 Parameter Transfer Designator

Function:	Selects the Parameters which will be returned in response to a transfer parameter request.
Units:	none
Range:	0 to 99
Default:	0 (all parameters)
Command Format:	L49 nn CRLF !L49 nnCRLF
Notes:	nn = 00 results in the transfer of all parameters in response to a parameter transfer request. nn = 01 to 99 results in the transfer of the designated parameter in response to a parameter transfer request. If nn is an invalid parameter, only a CRLF is returned.
Related L Codes:	L50 (Parameter Transfer Count)
Related H Codes:	H16 (Transfer Parameters)
Examples:	!L49 0 H16CRLF will cause all parameters to be transferred immediately. !L49 0 L50 0 H16CRLF will cause all parameters to be transferred immediately in three column format. !L50 4 L49 21 H16CRLF will result in four parameters being transferred starting at L21. Response: L21 nnCRLF L22 nnnnCRLF L23 nCRLF L25 nCRLF

L50 Parameter Transfer Count

Function:	Defines the number of parameters to be transferred in response to a Transfer Parameters (H16) request.
Units:	none
Range:	0 to 99
Default:	0
Command Format:	L50 nnCRLF !L50 nnCRLF
Notes:	The parameter count starts at the parameter specified by the L49 value. If L49 = 0, all parameters will be transferred. If L50 = 0 also, then a three L code per line transfer will occur.
Related L Codes:	L49 (Parameter Transfer Designator)
Related H Codes:	H16 (Transfer Parameters)
Example:	!L50 4 L49 21 H16CRLF will result in four parameters being transferred starting at L21. Response: L21 nnCRLF L22 nnnnCRLF L23 nCRLF L25 nCRLF

L51 Input/Output Mode Select

Function: This command allows additional inputs and outputs to be used in conjunction with the G20 (Condition Branch), G22 (Wait For Input) and G47 (Set Output Condition) commands.

Units: none

Range: 0 to 7

Default: 0

Command Format: L51 nCRLF

Notes:

L51 Value	Inputs				Outputs
	AWO	Step/Jog	CCW Direction	CW Direction	Strobes 4 thru 7
0	Normal	Normal	Normal	Normal	Normal
1	Normal	Input 7	Input 6	Input 5	Normal
2	Input 8	Normal	Normal	Normal	Normal
3	Input 8	Input 7	Input 6	Input 5	Normal
4	Normal	Normal	Normal	Normal	Outputs 3 thru 6
5	Normal	Input 7	Input 6	Input 5	Outputs 3 thru 6
6	Input 8	Normal	Normal	Normal	Outputs 3 thru 6
7	Input 8	Input 7	Input 6	Input 5	Outputs 3 thru 6

If L51=4 Through 7

Strobe 4 is Output 3, Strobe 5 is Output 4, Strobe 6 is Output 5 and Strobe 7 is Output 6. These outputs are used in conjunction with the G47 command.

G47 X00nnnnnn

00n----- Strobe 7 (L51= 4 thru 7)

00-n----- Strobe 6 (L51= 4 thru 7)

00--n---- Strobe 5 (L51= 4 thru 7)

00---n-- Strobe 4 (L51= 4 thru 7)

00----n- Output 2 (L51= 0 thru 7)

00-----n Output 1 (L51= 0 thru 7)

The AWO, Step/Jog, CCW Dir and CW Dir inputs can be reassigned as conditional inputs for the G20 and G22 commands.

G20 Xnnnnnnnn

G22 Xnnnnnnnn

n----- AWO (L51= 2,3,6 or 7)

-n----- Step/Jog (L51= 1,3,5 or 7)

--n----- CCW Dir (L51= 1,3,5 or 7)

---n----- CW Dir (L51= 1,3,5 or 7)

----n---- CCW Limit (L45= 1)

-----n-- CW Limit (L45= 1)

-----n- In 2 (L51= 0 thru 7)

-----n In 1 (L51= 0 thru 7)

L51 continued

If L51 = 4 thru 7, the following functions are lost:

G36 (Strobe X) ignored

G38 (Strobe F) ignored

parallel data for the L, X and F codes are disabled

If L51 = 1, 3, 5 or 7, the parallel Jog and Step functions are lost

If L51 = 2, 3, 6 or 7, the parallel Windings On/Off function is lost

L52 Buffer Warning Character

Function:	Defines the character to be sent when either buffer has ten characters or less remaining before it will overflow.
Units:	none
Range:	0 to 127 (0 = disabled)
Default:	0 (disabled)
Command Format:	L52 nnnCRLF !L52 nnnCRLF
Notes:	L52 value of 1 to 127 defines the ASCII code to be sent when ten characters or less remain before an overflow condition will occur. The character is sent only if the indexer ID is active. The character is only sent once, regardless of the Xoff status.
Example:	L52 66 CRLF sets "066" (B) as the character to be sent as a buffer overflow warning.

L55 Line Done Character

Function:	Defines the character to be sent when a program line is completed.
Units:	none
Range:	0 to 127 (0 = disabled)
Default:	0 (disabled)
Command Format:	L55 nnnCRLF !L55 nnnCRLF
Notes:	An L55 value from 1 to 127 determines the ASCII character to be sent upon completion of a program line (line 1 thru 400). The character is only sent if the indexer ID is active. The character will be sent once regardless of the Xoff status.
Example:	L55 69 CRLF sets "069" (E) as the character to be sent when a Line Done condition occurs.

L56 Program Done Character

Function:	Defines the character to be sent when the program is completed.
Units:	none
Range:	0 to 127 (0 = disabled)
Default:	0 (disabled)
Command Format:	L56 nnnCRLF !L56 nnnCRLF
Notes:	An L56 value from 1 to 127 designates the ASCII code to be sent upon completion of the program. The character is sent only if the indexer ID is active. The character will be sent regardless of the Xoff status.
Example:	L56 70 CRLF sets "070" (F) as the character to be sent when the program has been executed.

L57 Strobe 0, Strobe 1 Delay

Function:	Sets the <u>Strobe 0</u> and <u>Strobe 1</u> delay time for fetching switch input commands.
Units:	milliseconds per strobe
Range:	4 to 98 (even numbers only)
Default:	4
Command Format:	L57 nnnCRLF !L57 nnnCRLF
Example:	L57 8 CRLF sets the delay time for <u>Strobe 0</u> and <u>Strobe 1</u> to 8 milliseconds.

L66 Backlash Compensation

Function:	The L66 parameter selects the number of steps to be used as <i>backlash</i> compensation.
Units:	pulses
Range:	-99,999,999 to +99,999,999
Default:	+0 (disabled)
Command Format:	L66 snnnnnnnn CRLF
Notes:	<p><i>Backlash</i> Compensation will only be performed when the <i>index</i> direction matches the direction programmed for this parameter and the <i>index</i> is not a Step Index.</p> <p>When performing <i>Backlash</i> Compensation, the Indexer adds the L66 value to the <i>index</i> motion. Following the motion, the Indexer delays for the time programmed in the <i>Backlash</i> Delay register (L43), reverses direction and indexes the distance programmed for the L66 parameter.</p>
Examples:	<p>L66 +100CRLF sets up a clockwise direction <i>backlash</i> compensation of 100 pulses.</p> <p>L66 -100 sets up a counterclockwise direction <i>backlash</i> compensation of 100 pulses.</p>

L67 Auto Reverse

Function:	The L67 command enables or disables the Auto Reverse cycle.
Units:	none
Range:	0 = Auto Reverse cycle disabled 1 = Auto Reverse cycle enabled
Default:	0
Command Format:	L67 nCRLF
Description:	<p>When the L67 function is enabled, a Reverse <i>Index</i> move will be performed after an incremental <i>index</i> move and delay have been executed. The delay between moves is the Program Line Delay (L44) value.</p> <p>A <i>Backlash</i> cycle may be performed, if enabled.</p> <p>Auto Reverse is disabled when in the Absolute Position mode.</p>
Example:	L67 1CRLF enables the Auto Reverse function.

L70 Resolution

Function: Program the L70 parameter with the correct value for the desired positioning resolution.

Units: none

Default:
 1 = full-step drive (200 pulses per revolution)
 2 = half-step drive (400 pulses per revolution)
 5 = 1/5 step drive (1,000 pulses per revolution)
 10 = 1/10 step drive (2,000 pulses per revolution)
 125 = 1/125 step drive (25,000 pulses per revolution)

Command Format: L70 nnnCRLF

Notes: This code should be programmed first.

The following chart shows the values that can be used with the various Programmable Indexer models.

RESOLUTION REGISTER VALUES					
DRIVE MODEL	Resolution Register Value				
	1	2	5	10	125
3180-EPI	Full	Half	-	-	-
3180-EPI10	-	-	-	1/10	-
3180-EPI125	-	-	-	-	1/125
6180-EPI	Full	Half	-	-	-
6180-EPI10	-	-	-	1/10	-
6180-EPI125	-	-	-	-	1/125

The value entered for the L70 parameter determines the input limits for the L09, L12, L14, L71 and L73 values. These limits are:

- 1 115,000 pulses maximum
- 2 115,000 pulses maximum
- 5 115,000 pulses maximum
- 10 115,000 pulses maximum
- 125 1,875,000 pulses maximum

L70 nnn will be processed when motion has stopped unless a Feed Hold *index* pause is active.


Example: L70 125CRLF sets the motor drive translator to the 1/125 microstep mode.

L71 Ramp Frequency Limit


Function:	This parameter sets the maximum speed that any motion will be allowed to achieve.
Units:	pulses per second
Range:	1 to 115,000 for L70=1 1 to 115,000 for L70=2 1 to 115,000 for L70=5 1 to 115,000 for L70=10 1 to 1,875,000 for L70=125
Default:	115,000 for L70=1 115,000 for L70=2 115,000 for L70=5 115,000 for L70=10 1,875,000 for L70=125
Command Format:	L71 nnnnnnnCRLF
Notes:	If the value in any speed register exceeds the L71 value, the L71 value will be used as the default value for that register.
Example:	L71 20000 CRLF sets the maximum motion velocity limit to 20000 pulses per second.

L72 Ramp Profile Select


Function:	This command selects the ramp profile that will be used during any motion that requires acceleration and deceleration.
Units:	none
Range:	0 = trapezoidal ramp profile 1 = hyperbolic ramp profile 2 = "S" shaped ramp profile
Default:	0
Command Format:	L72 nCRLF
Notes:	<p>The three Diagrams show the available ramp profiles (trapezoidal, "S" and hyperbolic).</p> <p>With some combinations of motor and load, a nonlinear ramp profile ("S" or Hyperbolic) will allow ramping to and from higher speeds than would be possible using a linear profile.</p> <p>Selecting a ramp profile other than Trapezoidal will result in longer acceleration and deceleration times for a given Accel/Decel register value.</p>
Related L Codes:	L11 (Acceleration/Deceleration) L12 (Low Speed) L71 (Ramp Frequency Limit)
Example:	L72 2CRLF selects an "S" shaped ramp profile.



Trapezoidal Ramp Profile - Figure 6.2



"S" Ramp Profile - Figure 6.3



Hyperbolic Ramp Profile - Figure 6.4

L73 Deviation Frequency

Function:	The L73 parameter selects the change in motor speed that will occur each time a Target Velocity Increase (H31) or Target Velocity Decrease (H32) command is given.
Units:	pulses per second
Range:	1 to 115,000 for L70=1 1 to 115,000 for L70=2 1 to 115,000 for L70=5 1 to 115,000 for L70=10 1 to 1,875,000 for L70=125
Default:	10 for L70=1 20 for L70=2 50 for L70=5 100 for L70=10 1,250 for L70=125
Command Format:	L73 nnnnnnnCRLF
Notes:	The rate at which the motor speed will change is determined by value set for the Acceleration/Deceleration (L11) parameter. The Deviation Frequency function is available during all modes of operation, including <i>Low Speed</i> . If the speed rate is increased to the point where it exceeds the Ramp Limit (L71) value, the L71 value will be used as the default speed rate.
Related H Codes:	H31 (Target Velocity Increase) H32 (Target Velocity Decrease)
Example:	L73 100CRLF sets the deviation frequency at 100 pulses per second.

L98 Delay Between Continuous H Code Transmissions

Function:	Defines the delay between continuous H codes (%). See Section 6.2 for details on the Continuous H Code Transmission mode.
Units:	milliseconds
Range:	0 to 499
Default:	100
Command Format:	L98 nnnCRLF !L98 nnnCRLF

6.2 H CODE DESCRIPTIONS

H01 Cycle Start

Function:	This command starts program execution or restarts motion from a Feed Hold (\$) condition.
Default Mode:	none
Command Format:	H01CRLF
Notes:	A program consists of a series of program lines. Each line is made up of a Line Number (Nnnn), G Code (Gnn), Move Distance or G code data (Xsnnnnnnnn), and Feed Rate or G code data (Fnnnnnnnn). All of these fields need not be programmed on each line. The execution time of a program line includes the Program Line Delay (L44) value.
Related L Codes:	L06 (Line Execution Format)

H02 Step Mode

Function:	This command selects the <i>Step mode</i> and deselects the <i>Jog mode</i> for manual motion operation.
Default Mode:	<i>step mode</i> (on power turn-on)
Command Format:	H02CRLF
Notes:	<p>The H02 command does not cause motion to occur.</p> <p>When the Indexer is in the <i>Step mode</i> and an H06 (CW) or an H07 (CCW) command is given, the Indexer will step the motor in the desired direction. The step distance for this move is the value entered for the L13 (Step Increment) parameter.</p> <p>H02 will not be processed during a Feed Hold condition.</p>
Related L Codes:	L09 (Jog Speed) L13 (Step Increment)
Related H Codes:	H04 (<i>High Speed Mode</i>) H05 (<i>Low Speed Mode</i>) H06 (CW Direction) H07 (CCW Direction) H19 (Transfer Mode Status)

H03 Jog Mode

Function: The H03 command selects the *Jog mode* and deselects the *Step mode* for manual motion operation.

Default Mode: *Step Mode* (on power turn-on)

Command Format: H03CRLF

Notes: The H03 command does not cause motion to occur.

When the Indexer is in the *Jog mode* and an H06 (CW) or an H07 (CCW) command is given, the motor will Jog in the desired direction. The motor will jog until a Feed Hold or a Clear command is issued or until a limit is exceeded.

H03 will not be processed during a Feed Hold condition.

Related H Codes: H04 (*High Speed Mode*)
H05 (*Low Speed Mode*)
H06 (CW Direction)
H07 (CCW Direction)
H19 (Transfer Mode Status)

X CLEAR
\$ FEED HOLD

H04 High Speed Mode

Function: The H04 command selects the *High Speed* mode and deselects the *Low Speed* mode.

Default Mode: *High Speed* mode (on power turn-on)

Command Format: H04CRLF
!H04CRLF

Notes: The H04 command selects the L09 value as the *High Speed* rate for the Jog cycle or Step execution and the F value as the *High Speed* rate for Program Execution.

When a motion command is given, the motor will ramp from the *Low Speed* rate up to the rate programmed for the motion cycle that is occurring.

If !H04 is issued during *Low Speed* motion, the appropriate *High Speed* value will become the target velocity for the motion in progress.

Related L Codes: L09 (Jog Speed)

Related H Codes: H05 (*Low Speed Mode*)
H19 (Transfer Mode Status)

H05 Low Speed Mode

Function:	The H05 command selects the <i>Low Speed</i> mode and deselects the <i>High Speed</i> mode.
Default Mode:	<i>High Speed</i> mode (on power turn-on)
Command Format:	H05CRLF !H05CRLF
Notes:	<p>This command selects the L12 (<i>Low Speed</i>) parameter value as the velocity for a Jog cycle, Program Execution or Step Execution.</p> <p>If an !H05 command is issued during <i>High Speed</i> motion, the L12 (<i>Low Speed</i>) value becomes the target velocity for the motion in progress. The motor will be ramped down to the L12 (<i>Low Speed</i>) parameter value.</p>
Related H Codes:	H04 (<i>High Speed Mode</i>) H19 (Transfer Mode Status)
Related L Codes:	L12 (<i>Low Speed</i>)

H06 CW Direction

Function: This command is used to start a Jog or Step motion in the CW direction.

Default Mode: none

Command Format: H06CRLF

Notes: **If any motion other than CW manual motion is active or if a Program Cycle is active, The CW command will not be honored.**

The following chart lists the action which will occur with the possible combinations of inputs that affect CW Direction.

INPUTS THAT AFFECT CW DIRECTION			
CW MOTION	STEP/JOG	SPEED	FUNCTION
active	Jog (H03)	High (H04)	Ramp to Jog Speed rate and Jog
active	Jog (H03)	Low (H05)	Jog at Low Speed rate
active	Step (H02)	High (H04)	Ramp to Jog Speed rate and Step
active	Jog (H03)	Low (H05)	Step at Low Speed rate
active	Jog or Step	Low to High	Ramp to Jog Speed rate
active	Jog or Step	High to Low	Ramp to Low Speed rate

Related L Codes:
 L09 (Jog Speed)
 L12 (Low Speed)
 L13 (Step Increment)

Related H Codes:
 H02 (Step Mode)
 H03 (Jog Mode)
 H04 (High Speed Mode)
 H05 (Low Speed Mode)

H07 CCW Direction

Function: This command is used to start a Jog or Step motion in the CCW direction.

Default Mode: none

Command Format: H07CRLF

Notes: If any motion other than CCW manual motion is active or if a Program Cycle is active, The CCW command will not be honored.

The following chart lists the action which will occur with the possible combinations of inputs that affect CCW Direction.

INPUTS THAT AFFECT CCW DIRECTION			
CW MOTION	STEP/JOG	SPEED	FUNCTION
active	Jog (H03)	High (H04)	Ramp to Jog Speed rate and Jog
active	Jog (H03)	Low (H05)	Jog at Low Speed rate
active	Step (H02)	High (H04)	Ramp to Jog Speed rate and Step
active	Jog (H03)	Low (H05)	Step at Low Speed rate
active	Jog or Step	Low to High	Ramp to Jog Speed rate
active	Jog or Step	High to Low	Ramp to Low Speed rate

Related L Codes: L09 (Jog Speed)
L12 (Low Speed)
L13 (Step Increment)

Related H Codes: H02 (Step Mode)
H03 (Jog Mode)
H04 (High Speed Mode)
H05 (Low Speed Mode)

H08 Return To Electrical Home

Function: The H08 command will cause the Indexer to perform an *index* move to return to the location which has been designated *Electrical Home*. This is an Absolute position of zero.

Default Mode: none

Command Format: H08CRLF

Notes: The direction for a Return To *Electrical Home index* move will be the reverse of the direction of the present Absolute position and the distance will be that of the present Absolute electrical position.

Related H Codes: H04 (High Speed Mode)
H05 (Low Speed Mode)
H09 (Set Electrical Home)

Related L Codes: L14 (Home Speed)

H09 Set Electrical Home

- Function:** The H09 commands the Indexer to establish the present mechanical position as *Electrical Home* and Encoder Home Position.
- Default Mode:** none
- Command Format:** H09CRLF
- Notes:** All Absolute positions are referenced to the *Electrical Home* position.
- Upon power up, the present mechanical position will be established as *Electrical Home*. This home position will continue to be the *Electrical Home* position until a new *Set Electrical Home* command is given, a Return to *Mechanical Home* cycle is executed or until the Indexer is de-energized.
- H09 will not be processed while a Feed Hold condition is active.**

H10 Return To Mechanical Home

- Function:** This code commands the Indexer to perform a Return To *Mechanical Home* cycle.
- Default Mode:** none
- Command Format:** H10CRLF
- Notes:** When an H10 command is issued, the Indexer begins the cycle by Jogging in the direction selected by the L08 (*Mechanical Home* Direction) parameter.
- The Indexer will Jog until the Home Limit Switch input is activated and will then ramp to a halt. The point at which the Home Limit Switch input was activated will be registered as the temporary Home position.
- When motion ceases, the Indexer will *index* to the temporary Home position and will Jog at Low Speed (L12 value) until the Home Limit switch input becomes active and then inactive.
- The Indexer then reverses direction and Jogs at Low Speed (L12 value) until the Home Limit Switch input becomes active again. This position is then established as the Absolute Electrical Home Position.
- If a value other than 0 is entered for the *Mechanical Home* Offset (L17) parameter, the Indexer will now *index* this direction and distance. This position is then established as the Absolute *Electrical Home* Position.

Related L Codes:

L08 (*Mechanical Home* Direction)
L12 (*Low Speed*)
L14 (*Home Speed*)

See also p5-10

Related RS232 Commands:

H04 (*High Speed* Mode)
H05 (*Low Speed* Mode)

H11 Clear Program Line

Function: The H11 commands the Indexer to clear the present program line.

Default Mode: none

Command Format: H11CRLF

H12 Clear Program Lines Using L48

Function: This command, together with L48 = 0, will clear the entire program. The lines will be irretrievably erased and the line pointer will be reset to the line selected by L41.

Default Mode: none

Command Format: H12CRLF

Notes: If L48 = nnn and the H12 command is issued, nnn lines will be cleared starting from the current line.

Examples: L48 0 H12CRLF will clear lines 1 through 400.
N1 L48 10 H12CRLF will clear lines 1 through 10.

H13 Transfer Program Line

Function: Requests the transfer of the current program line.

Default Mode: none

Command Format: H13CRLF
!H13CRLF

Notes: The data will be transferred in the following format:
Nnnn Gnn Xsnnnnnnnn FnnnnnnnnCRLF

H14 Transfer Program Lines Using L48

Function: This command, together with L48, will send program lines.

Default Mode: none

Command Format: H14CRLF

Notes: If L48 = nnn and this command is given, nnn lines will be sent, starting from the current line.

The line data will be transferred in the following format:
Nnnn Gnn Xsnnnnnnnn FnnnnnnnnCRLF

If no value has been programmed for a program field, spaces will be sent in its place:
Nnnn Xsnnnnnnnn CRLF

Examples: L48 0 H14CRLF will send lines 1 through 400.
N1 L48 10 H14CRLF will send lines 1 through 10.

H15 Transfer Current Line Number

Function: This command requests the transfer of the current line number.

Default Mode: none

Command Format: H15CRLF
!H15CRLF

Notes: The data will be transferred in the following format:
NnnnCRLF

H16 Transfer Parameters

Function: The H16 command requests the transfer of all parameters (L codes) or of a designated parameter.

Default Mode: none

Command Format: H16CRLF
!H16CRLF

Notes: When L49 = 0, all parameters will be transferred. If L50 = 0 also, a three L code per line transfer will occur.

If the L49 value is a legal parameter number, see L Code Listing APPENDIX A, only the contents of that parameter will be transferred.

If the L49 value is not a legal parameter, only a CRLF will be returned.

Example: command: !L49 dd H16 CR or L49 dd H16 CR
where: "dd" is a legal code listed in APPENDIX A

response: Ldd (data) CRLF
where: "dd" consists of two ASCII characters from 0 to 9
(data) is field data for this parameter
CR is a Carriage Return
LF is a Line Feed

H17 Transfer Absolute Electrical Position

Function: This code requests the transfer of the Absolute Electrical Position.

Default Mode: none

Units: pulses

Command Format: H17CRLF
!H17CRLF

Notes: The data will be transferred in the following format:
snnnnnnnnnCRLF

H18 Transfer Motion Status

Function: The H18 code requests the transfer of the status of motion related inputs and functions.

Default Mode: none

Command Format: H18CRLF
!H18CRLF

Notes: The data will be transferred in the following format:
nnnnnnnnCRLF

<i>n-----</i>	<i>Stop Execution</i>	<i>0=inactive</i>	<i>1=active</i>
<i>-n-----</i>	<i>CCW Direction</i>	<i>0=inactive</i>	<i>1=active</i>
<i>--n-----</i>	<i>CW Direction</i>	<i>0=inactive</i>	<i>1=active</i>
<i>---n----</i>	<i>Feed Hold</i>	<i>0=inactive</i>	<i>1=active</i>
<i>----n---</i>	<i>Clear</i>	<i>0=inactive</i>	<i>1=active</i>
<i>-----n--</i>	<i>Home Limit</i>	<i>0=inactive</i>	<i>1=active</i>
<i>-----n-</i>	<i>CCW Limit</i>	<i>0=inactive</i>	<i>1=active</i>
<i>-----n</i>	<i>CW Limit</i>	<i>0=inactive</i>	<i>1=active</i>

The limits will only appear active if the last motion was in the designated direction and the limit sensor is active.

Example: !H18CRLF sent. The data transfer results might be as follows:
00001001CRLF
This transfer indicates that the "Clear" and the "CW Limit" are active. All others are inactive.

H19 Transfer Mode Status

Function: The H19 code requests the transfer of the status of the Indexer modes.

Default Mode: none

Command Format: H19CRLF
!H19CRLF

Notes: The data will be transferred in the following format:
nnnnnnnnCRLF

<i>n-----</i>	<i>Program Execution</i>	<i>0=inactive</i>	<i>1=active</i>
<i>-n-----</i>	<i>Motion</i>	<i>0=inactive</i>	<i>1=active</i>
<i>--n-----</i>	<i>0=Incremental Mode</i>	<i>1=Absolute Mode</i>	
<i>---n----</i>	<i>All Windings Off</i>	<i>0=inactive</i>	<i>1=active</i>
<i>----n---</i>	<i>Boost Current</i>	<i>0=inactive</i>	<i>1=active</i>
<i>-----n--</i>	<i>Reduced Current</i>	<i>0=inactive</i>	<i>1=active</i>
<i>-----n-</i>	<i>0=Low Speed Mode</i>	<i>1=High Speed Mode</i>	
<i>-----n</i>	<i>0=Step Mode</i>	<i>1=Jog Mode</i>	

Example: !H19CRLF sent. The following data transfer may result:
00100011CRLF

This data transfer indicates that the Absolute Mode, Jog Mode and High Speed mode are active. All others are inactive.

H20 Transfer Output Status

Function: Transfers the status of the Indexer outputs.

Default Mode: none

Command Format: H20CRLF
!H20CRLF

Notes: The data will be transferred as follows:

00nnnnnnnCRLF

<i>00n-----</i>	<i>Output 6 (L51 = 4 thru 7)</i>	<i>0= inactive</i>	<i>1= active</i>
<i>00-n----</i>	<i>Output 5 (L51 = 4 thru 7)</i>	<i>0= inactive</i>	<i>1= active</i>
<i>00--n---</i>	<i>Output 4 (L51 = 4 thru 7)</i>	<i>0= inactive</i>	<i>1= active</i>
<i>00---n--</i>	<i>Output 3 (L51 = 4 thru 7)</i>	<i>0= inactive</i>	<i>1= active</i>
<i>00----n-</i>	<i>Output 2</i>	<i>0= inactive</i>	<i>1= active</i>
<i>00-----n</i>	<i>Output 1</i>	<i>0= inactive</i>	<i>1= active</i>

Example: !H20CRLF sent. The following data transfer may result:
0000010CRLF

This data transfer indicates that Output 2 is active. All others are inactive.

H21 Transfer Conditional Input Status

Function: Transfers the status of the Indexer inputs.

Default Mode: none

Command Format: H21CRLF
!H21CRLF

Notes: The data will be transferred as follows:

nnnnnnnnnCRLF

<i>n-----</i>	<i>Input 8 (L51 = 2,3,6 or 7)</i>	<i>0= inactive</i>	<i>1= active</i>
<i>-n-----</i>	<i>Input 7 (L51 = 1,3,5 or 7)</i>	<i>0= inactive</i>	<i>1= active</i>
<i>--n-----</i>	<i>Input 6 (L51 = 1,3,5 or 7)</i>	<i>0= inactive</i>	<i>1= active</i>
<i>---n----</i>	<i>Input 5 (L51 = 1,3,5 or 7)</i>	<i>0= inactive</i>	<i>1= active</i>
<i>----n---</i>	<i>Input 4 (L45 = 1)</i>	<i>0= inactive</i>	<i>1= active</i>
<i>-----n--</i>	<i>Input 3 (L45 = 1)</i>	<i>0= inactive</i>	<i>1= active</i>
<i>-----n-</i>	<i>Input 2</i>	<i>0= inactive</i>	<i>1= active</i>
<i>-----n</i>	<i>Input 1</i>	<i>0= inactive</i>	<i>1= active</i>

Example: !H21CRLF sent. The following data transfer may result:
1000010CRLF

This data transfer indicates that Input 8 and Input 2 are active. All others are inactive.

H23 Transfer Software Revision Level

Function: The H23 and !H23 codes request the transfer of the Software Revision Level.

Default Mode: none

Command Format: H23CRLF
!H23CRLF

Notes: The data will be transferred in the following format:
EPI mm/yy/xCRLF
where:
EPI = Enhanced Indexer
mm = Month
yy = Year
x = Revision Level

H24 Program Trace Mode On

Function: This command causes the Indexer to transmit the contents of each line as it is executed during program execution.

Default Mode: Off

Command Format: H24CRLF
!H24CRLF

Notes: The data will be transmitted in the following format:
Nnnn Gnn Xsnnnnnnnn FnnnnnnnCRLF

If a value has not been programmed for a program field, spaces will be sent in its place.
Nnnn Xsnnnnnnnn CRLF

An unprogrammed line will not be sent.

H25 Program Trace Mode Off

Function: This command will cancel the Program Trace Mode.

Default Mode: Off

Command Format: H25CRLF
!H25CRLF

H28 Transfer Switch Input Status

Function: This command transfers the status of the Indexer switch inputs.

Default Mode: none

Command Format: H28CRLF
!H28CRLF

Notes: The data will be transferred as follows:

```
nnnnnnnnCRLF
n----- 0=Serial Position           1=Parallel Position
-n----- Home Limit                 0=inactive 1=active
--n----- Clear                     0=inactive 1=active
---n---- Feed Hold                   0=inactive 1=active
----n--- Cycle Stop                  0=inactive 1=active
-----n-- Cycle Start                0=inactive 1=active
-----n- 0=Low Speed Position        1=High Speed Position
-----n Load                         0=inactive 1=active
```

Example: !H28CRLF sent. The following data transfer may result:
11000010CRLF

This data transfer indicates that the Serial/Parallel, Home Limit and Low/High inputs are active. All others are inactive.

H29 Transfer Program Execution Time

Function: This command transfers the program execution time, in milliseconds.

Units: milliseconds

Default Mode: none

Command Format: H29CRLF
!H29CRLF

Notes: A Cycle Start command restarts the timing from zero (except when restarting from a Feed Hold condition). Timing is stopped by a Feed Hold, Clear, Program Line Error, Program Stop or Program Execution Complete.

Individual line execution times can be monitored in the Single Execution mode.

Times for executing entire programs can be monitored in the Automatic Execution mode.

Elapsed time from Program Start can be obtained in any mode using the immediate command (!H29).

Accuracy of the timing is +/-2 milliseconds.

The data will be transferred as follows:
nnnnnnnnnnCRLF

H30 Start Index From Run Cycle

Function:	This code requests the start of an <i>Index From Run</i> cycle using the present program line X and F values. If no X field is programmed, the distance and direction will be obtained from the external field data inputs.
Default Mode:	none
Command Format:	H30CRLF
Notes:	<p>The cycle begins with the Indexer starting a Jog cycle. During the Jog portion, Strobe 0 becomes the only active strobe. When the Home Limit/<i>Index From Run</i> input is recognized, the <i>index</i> value becomes active and the <i>index</i> portion of the cycle begins.</p> <p>The maximum distance travelled during an <i>Index From Run</i> cycle may be limited using the <i>Index From Run Travel Limit</i> (L16) parameter. This parameter limits the move in case the <i>Index</i> marker is missed.</p> <p><i>Index From Run</i> is not allowed in the Absolute mode.</p> <p>The maximum velocity allowed may be limited by the "X" value or by the Ramp Frequency Limit (L71).</p> <p>The repeatability of the <i>Index From Run</i> can be calculated as follows: Maximum Velocity/250 = Maximum error, in pulses</p> <p>For example, the repeatability of an <i>Index From Run</i> with an "F" value of 1000 is calculated as follows: 1000/250 = 4 pulses</p>
Related L Codes:	L12 (<i>Low Speed</i>)
Related H Codes:	H04 (<i>High Speed Mode</i>) H05 (<i>Low Speed Mode</i>)
Related Line Data Codes:	X (<i>Index Distance</i>) F (<i>Program High Speed Rate</i>)

H31 Target Velocity Increase

Function:	This command requests that the target velocity be increased by the Deviation Frequency (L73) value.
Default Mode:	none
Command Format:	!H31CRLF
Notes:	If the !H31 command is given while the motor is moving, the motor speed will increase by the Deviation Frequency (L73) value.
Related L Codes:	L20 (Up/Down Feed Rate Override) L73 (Deviation Frequency)

H32 Target Velocity Decrease

Function:	The H32 command requests that the target velocity be decreased by the Deviation Frequency (L73) value.
Default Mode:	none
Command Format:	!H32CRLF
Notes:	If the !H32 command is given while the motor is moving, the motor speed will decrease by the Deviation Frequency (L73) value.
Related L Codes:	L20 (Up/Down Feed Rate Override) L73 (Deviation Frequency)

H33 Incremental Position Mode

Function:	This command selects the Incremental Position mode. All moves will be made in the plus or minus direction from the present position .
Default Mode:	Incremental mode (H33)
Command Format:	H33CRLF
Notes:	H33 will be ignored if a Feed Hold (\$) is active.

H34 Absolute Position Mode

Function:	This command selects the Absolute Position mode. All moves in this mode are referenced from the <i>electrical home</i> position.
Default Mode:	Incremental mode (H33)
Command Format:	H34CRLF
Notes:	The Auto Reverse feature will be disabled when operating in the Absolute positioning mode. H34 will be ignored if a Feed Hold (\$) is active.

H35 Motor Windings On

Function:	The H35 code causes current to be applied to the motor windings at all times.
Default Mode:	Windings On (H35)
Command Format:	H35CRLF
Notes:	Use the H35 command when holding torque is required at standstill.

H36 Motor Windings Off

Function: This command causes current to be removed from the motor windings when motion ceases.

Default Mode: Windings On (H35)

Command Format: H36CRLF

Notes: Without winding current, the motor will have no holding torque. Therefore, **the H36 command should only be used when holding torque at standstill is not needed.**

Whenever the Motor Windings Off function is active, an additional time delay is introduced during programmed motion cycles to allow winding current to build in the motor prior to the start of motion and to decay after motion has occurred. This delay is approximately 50 milliseconds prior to motion and 50 milliseconds after motion has stopped. Therefore, the shortest possible time between moves is approximately 100 milliseconds.

When the Indexer is in the Windings Off mode, the Reduce Current feature will be ignored.

H37 Enable Boost Current

This command applies only to 3180 and 6180 Series models.

Function: When the H37 command is issued, motor winding current will be increased during acceleration and deceleration by 50% of the value set by the dip switches on the drive.

Default Mode: Disable Boost Current (H38)

Command Format: H37CRLF

Notes: When accelerating, boost current will be applied for the first 5 seconds, or until the motor has reached the programmed speed.

When decelerating, boost current will be applied for the first 5 seconds, or until the motor has stopped.

An additional time delay is introduced when the Boost Current feature is active to allow time for the motor winding current to build prior to motion and to decay after motion. This delay is approximately 50 milliseconds before the motion and 50 milliseconds after motion has stopped.

The Boost feature should be used when additional torque is needed for starting or stopping.

H38 Disable Boost Current

This command applies only to 3180 and 6180 Series models.

Function: This command cancels Boost current during acceleration and deceleration.

Default Mode: Disable Boost Current (H38)

Command Format: H38CRLF

H39 Enable Reduce Current

This command applies only to 3180 and 6180 Series models.

Function: This command will cause the motor current to be reduced at standstill by 50% of the value which has been selected on the drive. This condition lowers heating of the motor and also reduces holding torque at standstill.

Default Mode: Disable Reduce Current (H40)

Command Format: H39CRLF

Notes: An additional time delay is introduced during programmed motion cycles whenever the Reduce feature is active. This delay allows winding current to build in the motor prior to motion and to decay after motion has stopped. The delay is approximately 50 milliseconds prior to motion and 50 milliseconds after motion has stopped.

Activate the Reduce feature only when maximum holding torque at standstill is not needed.

The Reduce command will be ignored when the Windings Off feature is active.

H40 Disable Reduce Current

This command applies only to 3180 and 6180 Series models.

Function: This command cancels the Reduce Current mode.

Default Mode: Disable Reduce Current (H40)

Command Format: H40CRLF

H41 Transfer Remaining Repeat Value

Function: This command sends the remaining Repeat Count value.

Default Mode: none

Command Format: H41CRLF
!H41CRLF

Notes: If the present Repeat Count is zero and a Cycle Start command is given, the L47 (Repeat Count) value is transferred to the Repeat Count. The count remaining can be interrogated using this command.

The Repeat Count is decremented each time a Program End or line 400 is encountered during program execution.

The Repeat Count is zero when the Indexer is in the Continuous Execution or the Single Execution mode.

The data will be transferred in the following format:
nnnnnnnCRLF

H60 Transfer Present Velocity

Function: The H60 command requests that the present velocity be transferred.

Default Mode: none

Units: pulses per second

Command Format: H60CRLF
!H60CRLF

Notes: The data will be transferred in the following format:
nnnnnnnnnCRLF

H85 Transfer Motion Error Status

Function: The H85 command requests the transfer of the Motion Error status of the Indexer.

Default Mode: none

Command Format: H85CRLF
!H85CRLF

Notes: The data will be transferred in the following format:
OnnnnnnnCRLF

On----- Index From Run Limit Exceeded 0=inactive 1=active
O-n----- 0=Index ok 1=Index will be => CCW software limit
O--n---- 0=Index ok 1=Index will be => CW software limit
O---n--- CCW Software Limit 0=inactive 1=active
O----n-- CW Software Limit 0=inactive 1=active
O-----n- CCW Hard Limit 0=inactive 1=active
O-----n CW Hard Limit 0=inactive 1=active

H86 Transfer Data Error Status

Function: The H86 code is used to request the transfer of the Indexer's Data Error Status.

Default Mode: none

Command Format: H86CRLF
!H86CRLF

Notes: The format of the transferred data will be as follows:

```
nnnnnnnnCRLF
n----- Illegal L Code or Illegal G Code during a
           Jog cycle (G48)           0=inactive 1=active
-n----- L Code data out of range   0=inactive 1=active
--n----- Subroutine or Loop nesting 0=inactive 1=active
---n---- F data out of range         0=inactive 1=active
----n--- X data out of range         0=inactive 1=active
-----n-- N data out of range        0=inactive 1=active
-----n- Line requires F data        0=inactive 1=active
-----n Line requires X data         0=inactive 1=active
```

The Status bit assignments are:

Illegal L Code or Illegal G code during a Jog cycle (G48)

Set whenever an unassigned L Code data change is attempted or an illegal G code was executed during a Jog cycle (G48).

Reset when an assigned L Code is changed or when program execution begins.

L Code data out of range

Set when the data field for an L code is outside the legal range.

Reset when L Code data is in range or when program execution begins.

Subroutine or Loop Nesting

Set only during program execution if Subroutine or Loop nesting is detected.

Reset when program execution begins.

F data out of range

Set when a program line F value, !F value, Strobed F data (G38) or G20 F data is outside the legal range.

Reset when F data is in range or program execution begins.

X data out of range

Set during program execution if the X value is outside the legal range (1 to 400) for a G11 or G12 code.

Reset when program execution begins.

N data out of range

Set when an addressed line number is out of range (0 to 400) or during program execution if the Strobe N (G37) value is out of range (1 to 400).

Reset when an addressed line is in range or when program execution begins.

Line requires F data

Set during program execution if the F field is omitted on the following G Code commands: G11, G20 and G29.

Reset when program execution begins.

Line requires X data

Set during program execution if the X field is omitted on the following G Code commands: G10, G11, G12, G20, G22, G25, G47, G48 and G79.

Reset when program execution begins.

If a data error occurs during program execution, the line it occurred on can be interrogated using the H87 command.

H87 Transfer Program Error Line Number

Function: This command requests the transfer of the program line number with an error detected during program execution.

Default Mode: none

Command Format: H87CRLF
!H87CRLF

Notes: The data will be transferred in the following format:
NnnnCRLF (if program was terminated on a programming error)
CRLF (if no program error was detected)

H88 Transfer Active Cycle

Function: This command requests the transfer of the present active cycle.

Default Mode: none

Command Format: H88CRLF
!H88CRLF

Notes: The data will be transferred in the following format:
nnnnnnnnCRLF
n----- Program Execution 0= inactive 1= active
-n----- Return To Electrical Home 0= inactive 1= active
--n---- Return To Mechanical Home 0= inactive 1= active
---n--- Index From Run 0= inactive 1= active
----n-- Step CW 0= inactive 1= active
-----n-- Step CCW 0= inactive 1= active
-----n- Jog CW 0= inactive 1= active
-----n Jog CCW 0= inactive 1= active

When a Feed Hold has been executed, the pending cycle will still be active.

H99 Transfer Unit Type

Function: This command transfers the Factory established Unit designation.

Default Mode: none

Command Format: H99CRLF

Notes: Up to 32 characters and a CRLF will be sent in response to this command.

% Activate Continuous H Code Transfer Mode

Function: This command will set the active Indexer into the Continuous Transfer mode for designated H codes. When active the data requested by the designated H Code will be transferred continuously until the mode is canceled. This mode will be canceled by receipt of a code that is not one designated for continuous transfer.

Command Format: %HnnCRLF
%!HnnCRLF

Notes:

Nondesignated codes:
Lnn
Hnn
Xsnnnnnnnn
Fnnnnnnn
!Fnnnnnnn
<
*
<nn& (Listen Mode)

Designated H Codes:
H13 Transfer Program Line
H15 Transfer Current Line Number
H17 Transfer Absolute Electrical Position
H18 Transfer Motion Status
H19 Transfer Mode Status
H20 Transfer I/O Status
H60 Transfer Present Velocity
H85 Transfer Motion Error Status
H86 Transfer Data Error Status

% is ignored if the Listen mode is active (&).

The L98 (Delay Between Continuous H Codes) sets the delay between continuous H code transfers.

The L26 value should be 4, 5, 6 or 7 if the Xon/Xoff protocol is to be ignored during the transfers.

The restrictions for designated H codes will be honored. For example, !HnnCRLF will be honored during motion while HnnCRLF will not be honored until motion has stopped.

Transfer Format: (data)CRLF

6.3 G CODES, PREPARATORY COMMANDS

G codes are preparatory commands that are stored and executed within a program. Several G codes are modal commands which retain their state until canceled or superseded by a subsequent command.

Attempting to execute a G code without the required additional data fields will cause program execution to halt and the line number to be loaded with the L41 value.

The following G codes require additional data fields:

G04	Xnnnnnn	(Delay X Value)
G10	Xsnnnnnnnn	(Index From Run)
G11	Xnnn Fnnnn	(Call Subroutine Line X And Repeat F Times)
G12	Xnnn	(Go To Line X)
G20	Xnnnnnnnn Fnnn	(Branch On Input Condition X To Line F)
G22	Xnnnnnnnn	(Wait For Input Condition X)
G25	Xnnn	(Loop Start, repeat X times)
G29	Xnnnnnnnn Fnn	(Preload designated parameter)
G47	Xnnnnnn	(Output Condition X)
G48	Xs	(Start Jog Cycle)
G79	Xsnnnnnnnn	(Preload Electrical Absolute Position)

The following G codes are modal commands and require no additional data fields:

G27	(High Speed Mode)
G28	(Low Speed Mode)
G64	(Enable Reduced Current Mode)
G65	(Disable Reduced Current Mode)
G66	(Enable Boost Current Mode)
G67	(Disable Boost Current Mode)
G68	(Windings Off Mode)
G69	(Windings On Mode)
G90	(Absolute Mode)
G91	(Incremental Mode)

The following G codes do not require additional data fields:

G23	(Increment Jog Cycle Frequency)
G24	(Decrement Jog Cycle Frequency)
G26	(Loop End)
G30	(End Of Program)
G31	(Program Stop)
G32	(Return From Subroutine)
G36	(Strobe X Code Data)
G37	(Strobe N Code Data)
G38	(Strobe F Code Data)
G49	(Stop Jog Cycle)
G76	(Return To Electrical Home)
G77	(Set Electrical Home)
G78	(Return To Mechanical Home)

G04 Dwell Time

Function:	This command allows a delay to be entered into the program.
Units:	milliseconds (X field)
Range:	0 to 99,999
Default Mode:	none
Command Format:	G04 XnnnnnCRLF
Notes:	<p>If the value entered is greater than 99,999, it will default to the 99,999 limit.</p> <p>If no X value is entered, this command will be ignored.</p> <p>The F field, if programmed, will become the new <i>High Speed</i> rate.</p> <p>The G04 XnnnnnCRLF command will be entered on the present program line.</p> <p>The G04 command can be used during a Program Jog Cycle (a cycle started by a G48 command).</p>
Examples:	<p>N001 G04 X1000CRLF calls for a delay of 1 second.</p> <p>N001 G04 X1000 F2000CRLF calls for a delay of 1 second and changes the <i>High Speed</i> rate to 2000 pulses per second.</p>

G10 Start Index From Run

Function: This command requests the start of an *Index From Run* cycle.

Units: pulses

Range: -99,999,999 to +99,999,999 (X field)

Default Mode: none

Command Format: G10 Xsnnnnnnnn CRLF

Notes: The distance and direction of an *Index From Run* is defined by the X field or the external field data inputs. If no X field is programmed, the distance and direction will be obtained from the external field data inputs.

The maximum distance travelled during an *Index From Run* cycle may be limited using the *Index From Run Travel Limit* (L16) parameter. This parameter limits the move in case the *Index* marker is missed.

If an F field is programmed, that value will become the *High Speed* rate for the cycle. Otherwise, the previously programmed rate becomes the *High Speed* rate.

The cycle begins with the Indexer starting a Jog cycle. During the Jog portion, Strobe 0 becomes the only active strobe. When the Home Limit/*Index From Run* input is recognized, the *index* value becomes active and the *index* portion of the cycle begins. If an *Index From Run* cycle is halted by a Feed Hold, it can be resumed by issuing a Cycle Start command.

The maximum velocity may be limited by the X value or by the Ramp Frequency Limit (L71).

The repeatability of the *Index From Run* can be calculated as follows:

$$\text{Maximum Velocity}/250 = \text{Maximum Error, in pulses}$$

For Example, The repeatability of an *Index From Run* cycle (Nnnn G10 Xsnnnnnnnn F1000) command is:

$$1000/250 = 4 \text{ pulses}$$

Related L Codes: L12 (*Low Speed*)

Related RS232 Commands: H04 (*High Speed Mode*)
H05 (*Low Speed Mode*)

G11 Call A Subroutine

Function:	This command calls a subroutine line (X) and repeats this subroutine call (F) times.
Units:	line number (X field); repeat count (F field)
Range:	1 through 400 for X field; 0 through 9,999 for F field
Default Mode:	none
Command Format:	G11 Xnnn FnnnnCRLF
Notes:	<p>The X field is the subroutine line number. If this field is missing or out of range, program execution will stop and the line number will be loaded with the L41 value.</p> <p>The F field is the subroutine repeat count. The number of times the subroutine will be repeated is the F field value plus one. If this field is missing, program execution will stop and the line number will be loaded with the L41 value.</p> <p>Subroutine nesting (calling a subroutine within a subroutine) is not allowed. If subroutine nesting is attempted, program execution will stop and the line number will be loaded with the L41 value.</p> <p>When a Return From Subroutine (G32) command is encountered during a subroutine, the Indexer returns to the line calling the subroutine and begins the subroutine again. This cycle is repeated F + 1 times. The Indexer will then go on to the next program line.</p>

Related G Codes: G32 (Return From Subroutine)

Example: The following program executes ten moves of 200 pulses each, and then stops. The L06 value is 2. The execution command is "N1H1CRLF".

```
N001 G11 X10 F9      (call line 10 and repeat 9 times)
N002 G30             (end of program)
N10 G91 X200 F500   (index 200 pulses at 500 pulses per second)
N11 G32             (return from subroutine)
```

G12 Go To Line Number

Function:	This command tells the Indexer to go to the line specified by the X field.
Units:	line number (X field)
Range:	1 through 400 (X field)
Default Mode:	none
Command Format:	G12 XnnnCRLF
Notes:	<p>The X field is the line number. If this field is missing or is out of range, program execution will stop and the line number will be loaded with the L41 value.</p> <p>The G12 command causes the X value to be loaded as the line number.</p>
Example:	The execution of N010 G12 X2 sets the line number to 2.

G20 Conditional Branch

Function: This command tells the Indexer to go to line Fnnn if the input condition specified by the X field occurs. If the specified condition does not occur, the Indexer goes on to the next line.

Units: line number (F field)

Range: 1 through 400 (F field)

Default Mode: none

Command Format: G20 Xnnnnnnnn FnnnCRLF

Notes: The X field specifies the input condition for the branch. If this field is missing, program execution will stop and the line number will be loaded with the L41 value.

The X field input assignments are as follows:

```
Xnnnnnnnn
n----- Input 8           if L51= 2,3,6,7
-n----- Input 7           if L51= 1,3,5,7
--n----- Input 6          if L51= 1,3,5,7
---n----- Input 5          if L51= 1,3,5,7
----n---- Input 4           if L45= 1
-----n-- Input 3           if L45= 1
-----n- Input 2
-----n Input 1
```

If the L51 or L45 value is not met, that bit will be ignored.

The programmable input condition for each bit is a value from 0 to 9. A value of 0 requires the input to be inactive. A value of 1 requires the input to be active. A value from 2 to 9 indicates a "don't care" condition.

The F field represents the line number the Indexer will branch to. If this value is missing or out of range, program execution will stop and the line number will be loaded with the L41 value.

Examples:

Example 1

L51= 1, L45= 0, and the following line is executed:
N10 G20 X11201101 F20

```
1----- ignored (only used if L51= 2,3,6,7)
-1----- Input 7 active
--2----- Input 6 don't care
---0----- Input 5 inactive
----1---- ignored (only used if L45= 1)
-----1-- ignored (only used if L45= 1)
-----0- Input 2 inactive
-----1 Input 1 active
```

If the above condition is met, go to line 20. Otherwise, go to line 11.

G20 Code continued

Example 2

L51= 2, L45= 0 and the following line is executed:

N10 G20 X11201101 F20

*1----- Input 8 inactive
-1----- ignored (only used if L51= 1,3,5,7)
--2----- ignored (only used if L51= 1,3,5,7)
---0----- ignored (only used if L51= 1,3,5,7)
----1---- ignored (only used if L45= 1)
-----1-- ignored (only used if L45= 1)
-----0- Input 2 inactive
-----1 Input 1 active*

If the above condition is met, go to line 20. Otherwise, go to line 11.

Example 3

L51= 3, L45= 1 and the following line is executed:

N10 G20 X11001101 F20

*1----- Input 8 active
-1----- Input 7 active
--0----- Input 6 inactive
---0----- Input 5 inactive
----1---- Input 4 active
-----1-- Input 3 active
-----0- Input 2 inactive
-----1 Input 1 active*

If the above condition is met, go to line 20. Otherwise, go to line 11.

G22 Wait For Input

Function: This command causes the program to wait until the states of the inputs match the X field values.

Units: none

Range: 0 to 99999999 (X field)

Default Mode: none

Command Format: G22 XnnnnnnnnCRLF

Notes: The X field specifies the input conditions for the "wait". If this field is missing, program execution will stop and the line number will be loaded with the L41 value.

The X field input assignments are as follows:

```
Xnnnnnnnn
n----- Input 8          if L51= 2,3,6,7
-n----- Input 7          if L51= 1,3,5,7
--n----- Input 6          if L51= 1,3,5,7
---n---- Input 5          if L51= 1,3,5,7,
----n--- Input 4          if L45= 1
-----n-- Input 3          if L45= 1
-----n- Input 2
-----n Input 1
```

If the L51 or L45 value is not met, that bit will be ignored.

The programmable input condition for each bit is a value from 0 to 9. A value of 0 requires the input to be inactive and a value of 1 requires the input to be active. Values from 2 to 9 indicate a "don't care" condition.

The F field value, if programmed, will become the new *High Speed* rate.

Examples:

Example 1

L51= 1, L45= 0 and the following line is executed.

```
N10 G22 X11201101
```

```
1----- ignored (only used if L51= 2,3,5,7)
-1----- Input 7 active
--2----- Input 6 don't care
---0---- Input 5 inactive
----1--- ignored (only used if L45= 1)
-----1-- ignored (only used if L45= 1)
-----0- Input 2 inactive
-----1 Input 1 active
```

When the above condition is met, the line number is advanced to 11.

Example 2

L51= 2, L45= 0 and the following line is executed:

N10 G22 X11201101

*1----- Input 8 active
-1----- ignored (only used if L51= 1,3,5,7)
--2----- ignored (only used if L51= 1,3,5,7)
---0---- ignored (only used if L51= 1,3,5,7)
----1--- ignored (only used if L45= 1
-----1-- ignored (only used if L45= 1)
-----0- Input 2 inactive
-----1 Input 1 active*

When the above condition is met the line number is advanced to 11.

Example 3

L51= 3, L45= 1 and the following line is executed:

N10 G22 X11001101

*1----- Input 8 active
-1----- Input 7 active
--0----- Input 6 inactive
---0---- Input 5 inactive
----1--- Input 4 active
-----1-- Input 3 active
-----0- Input 2 inactive
-----1 Input 1 active*

When the above condition is met, the line number is advanced to 11.

G23 Increment Jog Cycle Frequency

Function:	This command causes the velocity to be incremented by the L73 value.
Units:	none
Range:	none
Default Mode:	none
Command Format:	G23CRLF
Notes:	<p>This command is only active if a programmed Jog (G48) cycle is taking place. The program will pause until the commanded velocity is attained.</p> <p>The maximum velocity which can be achieved is limited by the Ramp Frequency Limit parameter (L71).</p> <p>The X and F fields should not be programmed.</p> <p>The G23 command will be ignored if a programmed Jog cycle is not taking place.</p>

Example: Ramp from *Low Speed* to 500 pulses per second. Delay one second and increment the velocity by 100 pulses per second. Repeat this sequence nine times. The velocity is now 1500 pulses per second.

Delay one second and decrement the velocity by 100 pulses per second. Repeat this sequence nine times. The velocity is now 500 pulses per second. Delay one second and then stop.

L73= 100, L41= 1, L06= 2 and the following program is executed.

N1 G48 X+ F500	start Jog cycle <i>High Speed</i> 500 pps
N2 G11 X10 F9	go to subroutine line 10 and repeat 9 times
N3 G11 X13 F9	go to subroutine line 13 and repeat 9 times
N4 G04 X1000	delay 1 second
N5 G49	stop Jog cycle
N6 G30	end of program
N10 G04 X1000	delay 1 second
N11 G23	increment velocity by 100
N12 G32	return from subroutine
N13 G04 X1000	delay 1 second
N14 G24	decrement velocity by 100
N15 G32	return from subroutine

G24 Decrement Jog Cycle Frequency

Function:	This command causes the velocity to be decremented by the L73 value.
Units:	none
Range:	none
Default Mode:	none
Command Format:	G24CRLF
Notes:	This command is only active if a programmed Jog (G48) cycle is taking place. The program will pause until the commanded velocity is attained.

The X and F fields should not be programmed.

The G24 command will be ignored if a programmed Jog cycle is not taking place.

Example: Ramp from *Low Speed* to 500 pulses per second. Delay one second and increment the velocity by 100 pulses per second. Repeat this sequence nine times. The velocity is now 1500 pulses per second.

Delay one second and decrement the velocity by 100 pulses per second. Repeat this sequence nine times. The velocity is now 500 pulses per second. Delay one second and then stop.

L73= 100, L41= 1, L06= 2 and the following program is executed.

N1 G48 X+ F500	start Jog cycle <i>High Speed</i> 500 pps
N2 G11 X10 F9	go to subroutine line 10 and repeat 9 times
N3 G11 X13 F9	go to subroutine line 13 and repeat 9 times
N4 G04 X1000	delay 1 second
N5 G49	stop Jog cycle
N6 G30	end of program
N10 G04 X1000	delay 1 second
N11 G23	increment velocity by 100
N12 G32	return from subroutine
N13 G04 X1000	delay 1 second
N14 G24	decrement velocity by 100
N15 G32	return from subroutine

G25 Loop Start

Function: Defines the start of a Loop and repeats this loop X times.

Units: repeat count (X field)

Range: 0 to 9999 (X field)

Command Format: G25 XnnnnCRLF

Notes: The Execution Loop are lines executed from the loop start (G25) to the loop end (G26) command. When the loop is completed the line following the loop end (G26) will be executed.

The X field is the loop repeat count. The number of loop executions is the X value + 1. If this field is missing program execution will halt and the line number is loaded with the L41 value.

Loop nesting, calling another loop in a loop, is not allowed. If loop nesting occurs the program execution will halt and the line number is loaded with the L41 value.

A Loop can exist inside a Subroutine.

Related G codes: G26 (loop end)

Example: The following program executes 10 moves of 1000 pulses each and stops. The L06 value is 2. The execution command is "N1H1CRLF".

```
N1 G25 X9           (Loop start; repeat 9 times)
N2 G91 X1000       (index 1000 pulses)
N3 G26             (Loop end)
N4 G30             (End of Program)
```

G26 Loop End

Function: Defines the Loop End.

Units: none

Range: none

Command Format: G26CRLF

Notes: When encountered during a Loop (G25) restores the loop start line number.

Continues on with the next line when the Loop Start repeat count becomes 0.

Related G codes: G25 (loop start)

G27 High Speed Mode

Function:	Sets the <i>High Speed</i> Mode of Operation.
Units:	none
Range:	none
Command Format:	G27CRLF
Notes:	The X field value, if programmed, will become the <i>index</i> distance and direction. The F field value, if programmed, will become the new <i>High Speed</i> value.
Related H Codes:	H4 (<i>High Speed</i> Mode) H5 (<i>Low Speed</i> Mode)
Related G Codes:	G28 (<i>Low Speed</i> Mode)
Example:	Select the <i>High Speed</i> Mode of Operation during Program Execution. N001 G27CRLF

G28 Low Speed Mode

Function:	Sets the <i>Low Speed</i> Mode of Operation.
Units:	none
Range:	none
Command Format:	G28CRLF
Notes:	The X field value, if programmed, will become the <i>index</i> distance and direction. The F field value, if programmed, will become the new <i>High Speed</i> value.
Related H codes:	H4 (<i>High Speed</i> Mode) H5 (<i>Low Speed</i> Mode)
Related G Codes:	G27 (<i>High Speed</i> Mode)
Example:	Select the <i>Low Speed</i> Mode of Operation during Program Execution. N002 G28CRLF

G29 Preload Designated Parameter

Function: Preloads the designated Parameter (F field) with the X field data.

Units: Parameter (F field); Data (X field)

Range: designated L Codes listed below (F field)

L Code	parameter range (X field)
L07	Strobe delay (0 to 9999)
L08	<i>Mechanical Home</i> Direction (+ or -)
L09	Jog Speed (L70 dependent)
L11	Acc/Dcc (1 to 99999999)
L12	<i>Low Speed</i> (L70 dependent)
L13	Step Size (1 to 99999999)
L14	Home Speed (L70 dependent)
L16	<i>Index</i> From Run Limit (0 to 99999999)
L17	<i>Mechanical Home</i> Offset (-99999999 to +99999999)
L18	CW Software Travel Limit (-99999999 to +99999999)
L19	CCW Software Travel Limit (-99999999 to +99999999)
L20	Up/Down Feedrate Override (0 or 1)
L41	Auto Start Line Number (1 to 400)
L43	Delay between <i>Index</i> and <i>Backlash</i> cycle (0 to 9999)
L44	Program Line Delay (0 to 9999)
L45	Limit Enable/ Disable (0 or 1)
L47	Repeat Count (0 to 99999999)
L51	Input/Output Mode Select (0 to 7)
L52	Buffer Overflow Tx character (0 to 127)
L55	Line Done Tx character (0 to 127)
L56	Program Done Tx character (0 to 127)
L57	Strobe 0 & 1 delay (4 to 98)
L66	<i>Backlash</i> Compensation (-99999999 to +99999999)
L67	Auto Reverse (0 or 1)
L71	Ramp Frequency Limit (L70 dependent)
L72	Ramp Profile Select (0 to 2)
L73	Deviation Frequency for Up/Down command (L70 dependent)

Command Format: G29 Xsnnnnnnnn Fnn CRLF

Notes: If the F field is not one of the above parameters the cycle will be terminated and the line number will become the L41 value.

If the X field data is outside the designated parameter range the cycle will be terminated and the line number will become the L41 value.

If the X field is omitted the external field data will be strobed in.

Example: Change the ramp profile during program execution to the following:

```
L12= 300; L11= 15000; L71= 15000; L72= 2.
N001 G29 X300 F12 (L12 300)
N002 G29 X15000 F11 (L11 15000)
N003 G29 X15000 F71 (L71 15000)
N004 G29 X2 F72 (L72 2)
```

G30 End Of Program

Function:	This command denotes the end of the program and resets the line pointer to the line designated by the L41 parameter.
Units:	none
Range:	none
Default Mode:	none
Command Format:	G30CRLF
Notes:	<p>In the Automatic Execution mode, the number of times the program will repeat is the L47 parameter plus one. The line pointer will be reset to the line designated by the L41 parameter each time the G30 command is encountered.</p> <p>In the Continuous Execution mode, the program will execute continuously until a Program Stop command or a Clear command is encountered. The line pointer will be reset to the line designated by the L41 parameter each time the G30 command is encountered.</p> <p>The X and F fields are ignored.</p> <p>If no G30 command is incorporated, program line 400 becomes the End Of Program.</p>

G31 Program Stop

Function:	This command causes the program to stop executing and the line pointer to reset to the next program line.
Units:	none
Range:	none
Default Mode:	none
Command Format:	G31CRLF
Notes:	<p>Program execution can be resumed after a Program Stop command by issuing a Cycle Start command.</p> <p>The X and F fields are ignored.</p>

G32 Return From Subroutine

Function:	This command, used in conjunction with a G11, indicates the end of a subroutine.
Units:	none
Range:	none
Default Mode:	none
Command Format:	G32CRLF
Notes:	<p>If this command is encountered with no subroutine call pending, program execution will stop and the line number will be loaded with the L41 value.</p> <p>When this command is encountered during a subroutine call, the line pointer will be restored to the G11 line number.</p> <p>The X and F fields are ignored.</p>
Related G Codes:	G11 (Call a Subroutine)

G36 Strobe X Code Data

Function:	During program execution, the G36 command will cause the Indexer to load the parallel data inputs. The field data entry becomes the X field for the program line.
Units:	none
Range:	none
Default Mode:	none
Command Format:	G36CRLF
Notes:	<p>If an X field is programmed for the line containing a G36 command, it will be ignored.</p> <p>The F field, if programmed, will become the new <i>High Speed</i> rate.</p> <p>If L51= 4,5,6 or 7, this command will be ignored.</p>
Example:	Nnnn G36 F1000CRLF will load the parallel data distance and direction and will execute that motion using a <i>High Speed</i> rate of 1000 pulses per second.

G37 Strobe N Code Data

Function:	During program execution, the G37 command will cause the Indexer to load the parallel data inputs. The Code data entry becomes the active program line number.
Units:	none
Range:	1 through 400 (External Code Data)
Default Mode:	none
Command Format:	G37CRLF
Notes:	<p>The Code data entry becomes the line number. If this value is out of the permissible range of 1 through 400, program execution will stop and the line number will be loaded with the L41 parameter.</p> <p>The X and F fields are ignored.</p>

G38 Strobe F Code Data

Function:	During program execution, the G38 command will cause the Indexer to load the parallel data inputs. The fields data entry becomes the F field for the program line.
Units:	none
Range:	External Field Data 1 thru 115,000 pulses per second for L70 = 1 1 thru 115,000 pulses per second for L70 = 2 1 thru 115,000 pulses per second for L70 = 5 1 thru 115,000 pulses per second for L70 = 10 1 thru 1,875,000 pulses per second for L70 = 125
Default Mode:	none
Command Format:	G38CRLF
Notes:	<p>When this command is issued, the parallel data input becomes the new program feed rate. If this data is out of the permissible range, program execution will stop and the line number will be loaded with the L41 value.</p> <p>The X field value, if programmed, will become the <i>index</i> distance and direction.</p> <p>If the G38 command is encountered during a program Jog cycle, the parallel data input value becomes the new target velocity.</p> <p>If programmed, the F field for the line will be ignored.</p> <p>If L51= 4,5,6 or 7, this command will be ignored.</p>
Examples:	Nnnn G38 X-1000 will execute an <i>index</i> of -1000 at the <i>High Speed</i> rate selected by the parallel data input value.

G47 Set Output Condition

Function:	During program execution, the G47 command sets the programmable output states to the value of the X field.
Units:	none
Range:	0 to 999,999 (X field)
Default Mode:	none
Command Format:	G47 XnnnnnnCRLF

Notes: The programmable output condition for each bit is a value from 0 through 9. A value of 0 sets the output to the inactive state and a value of 1 sets the output to the active state. Values from 2 through 9 indicate no change to the output state.

The X field is the output condition. If this field is missing, program execution will stop and the line number will be loaded with the L41 value.

The X field output assignments are as follows:

```
Xnnnnnn
n----- Output 6      (L51= 4,5,6,7)
-n---- Output 5      (L51= 4,5,6,7)
--n--- Output 4      (L51= 4,5,6,7)
---n-- Output 3      (L51= 4,5,6,7)
----n- Output 2
-----n Output 1
```

If the L51 value condition is not met, that bit will be ignored.

The F field value, if programmed, will become the *High Speed* rate value.

Examples:

Example 1

L51 = 0 and the following line is executed.

```
Nnnn G47 X111101
1----- ignored (used only if L51= 4,5,6,7)
-1---- ignored (used only if L51= 4,5,6,7)
--1--- ignored (used only if L51= 4,5,6,7)
---1-- ignored (used only if L51= 4,5,6,7)
----0- Output 2 inactive
-----1 Output 1 active
```

Example 2

L51 = 4 and the following line is executed.

```
Nnnn G47 X101020
1----- Output 6 active
-0---- Output 5 inactive
--1--- Output 4 active
---0-- Output 3 inactive
----2- Output 2 no change
-----0 Output 1 inactive
```

G48 Start Jog Cycle

Function: During program execution, a G48 command starts a Jog cycle in the X direction. The feed rate will be the Jog Speed parameter unless an F field is part of the program line.

Units: none

Range: none

Default Mode: none

Command Format: G48 Xs CRLF

Notes: In the Single Line execution mode, a G48 command will start a Continuous Line Execution condition until a Stop Jog Cycle (G49) command is encountered.

The following line commands will be honored once a Jog cycle is started.

Nnnn Fnnnnnn	(ramp to velocity F)
Nnnn G04 Xnnnnnn	(delay X milliseconds)
Nnnn G04 Xnnnnnn Fnnnnnn	(delay X milliseconds, then ramp to velocity F)
Nnnn G11 Xnnn Fnnnn	(call subroutine line X and repeat F times)
Nnnn G12 Xnnn	(go to line X)
Nnnn G20 Xnnnnnnnn Fnnn	(branch on input condition X to line F)
Nnnn G22 Xnnnnnnnn	(wait for input condition X)
Nnnn G22 Xnnnnnnnn Fnnnnnn	(wait for input condition X, then ramp to velocity F)
Nnnn G23	(increment present velocity by L73 value)
Nnnn G24	(decrement present velocity by L73 value)
Nnnn G25 Xnnnn	(Loop Start; Repeat X times)
Nnnn G26	(Loop End)
Nnnn G27	(High Speed Mode)
Nnnn G28	(Low Speed Mode)
Nnnn G32	(return from subroutine)
Nnnn G37	(strobe N value and go to this line)
Nnnn G38	(ramp to the strobed F value)
Nnnn G47 Xnnnnnn	(output condition X)
Nnnn G47 Xnnnnnn Fnnnnnn	(output condition X, then ramp to velocity F)
Nnnn G49	(stop Jog cycle)

The X field sign designates the Jog cycle direction. If this field is missing, program execution will stop and the line number will be loaded with the L41 value.

The F field value, if programmed, will become the feed rate override value. Therefore, the target velocity will become the F field value.

The program cycle will be terminated by any of the following:

- execution of a G code other than those listed above
- a Clear (*) request
- a Feed Hold (\$) request
- execution of line 400
- index motion called for before G49 encountered

Related G Codes: G49 (Stop Jog Cycle)

G48 continued

Example:

Start a Jog Cycle. If the CCW LIMIT input is active strobe the external field data and make it the *High Speed* target value. Set Output 2 inactive and Output 1 active. Delay 100 milliseconds and then increment the velocity 200 pulses/sec. Repeat this 9 times. Delay 100 milliseconds and then decrement the velocity 200 pulses/sec. Repeat this 9 times. Set Output 2 active and Output 1 inactive. Stop the Jog Cycle. Wait for CW LIMIT input to be inactive. If INPUT 2 is active end the program. If INPUT 1 is active delay 1 second. Set Output 2 inactive and Output 1 inactive. Repeat program starting at line 1.

L06= 2, L41= 1, L45= 1, L47= 0, L51= 0, L73= 200

```
N001 G48 X- F300      (start CCW Jog, ramp to 300 pps)
N002 G20 X0222 F4    (if CCW Limit inactive, go to line 4)
N003 G38              (ramp to Strobe F velocity)
N004 G47 X01         (Output 2 inactive, Output 1 active)
N005 G11 X17 F9      (go to subroutine line 17 and repeat 9 times)
N006 G11 X20 F9      (go to subroutine line 20 and repeat 9 times)
N007 G47 X10         (Output 2 active, Output 1 inactive)
N008 G49             (stop Jog cycle)
N009 G22 X2022       (If CCW Limit active, wait for inactive condition)
N010 G20 X2212 F23   (if Input 2 active, end program)
N011 G20 X2220 F13   (if Input 1 active, delay 1 second)
N012 G04 X1000       (delay 1 second)
N013 G47 X00         (Output 2 inactive, Output 1 inactive)
N014 G12 X1          (go to line 1)
N017 G04 X100        (delay 100 milliseconds)
N018 G23             (increment velocity by 200 pps)
N019 G32             (return from subroutine)
N020 G04 X100        (delay 100 milliseconds)
N021 G24             (decrement velocity by 200 pps)
N022 G32             (return from subroutine)
N023 G30             (end of program)
```

G49 Stop Jog Cycle

Function: This command will cause a Jog cycle to come to a controlled stop.

Units: none

Range: none

Default Mode: none

Command Format: G49CRLF

Notes: When this command is issued, a programmed Jog cycle will come to a controlled stop and program execution will pause until motion has stopped.

The G49 command will be ignored if a programmed Jog cycle is not in process.

The X and F fields will be ignored.

Related G Codes: G48 (Start Jog Cycle)

G64 Enable Reduce Current

This command applies only to 3180 and 6180 Series models.

Function: This command causes the motor current to be reduced at standstill to 50% of the value selected on the drive. Reducing the motor current lowers motor heating and also reduces holding torque at standstill.

Units: none

Range: none

Default Mode: disable Reduce Current

Command Format: G64CRLF

Notes: When the Reduce Current feature is active, an additional time delay is introduced during programmed motion cycles. This delay allows winding current to build in the motor prior to motion and to decay after motion has stopped. The delay is approximately 50 milliseconds prior to motion and 50 milliseconds after motion has stopped. Therefore, the shortest possible time between moves is approximately 100 milliseconds.

The Reduce Current feature should only be used when maximum holding torque at standstill is not needed.

The X field, if programmed, will define the *index* distance and direction.

The F field, if programmed, becomes the *High Speed* velocity

The Reduce Current command will be ignored when the Windings Off feature is active.

Related G Codes: G65 (disable Reduce Current)

G65 Disable Reduce Current

This command applies only to 3180 and 6180 Series models.

Function: This command cancels the Reduce Current mode.

Units: none

Range: none

Default Mode: Disable Reduce Current

Command Format: G65CRLF

Notes: Canceling a Reduce Current condition with the G65 command will provide maximum holding torque at standstill and will also permit slightly shorter cycle times.

The X field, if programmed, defines the *index* distance and direction.

The F field, if programmed, becomes the *High Speed* velocity.

Related G Codes: G65 (disable Reduce Current)

G66 Enable Boost Current

This command applies only to 3180 and 6180 Series models.

Function:	The G66 command will cause the motor current to be increased during acceleration and deceleration by 50% of the value set on the drive.
Units:	none
Range:	none
Default Mode:	Disable Boost Current
Command Format:	G66CRLF
Notes:	<p>When accelerating Boost Current will be applied for the first 5 seconds, or until the motor has reached the programmed speed.</p> <p>When decelerating, Boost Current will be applied for the first 5 seconds, or until the motor has stopped.</p> <p>When the Boost Current feature is active, an additional time delay is introduced to allow time for motor winding current to build prior to motion and to decay after motion has stopped. This delay is approximately 50 milliseconds prior to motion and 50 milliseconds after motion has stopped.</p> <p>The X field, if programmed, defines the <i>index</i> distance and direction.</p> <p>The F field, if programmed, becomes the <i>High Speed</i> velocity.</p> <p>The Boost Current feature should be used when additional torque is needed for starting or stopping.</p>
Related G Codes:	G67 (Disable Boost Current)

G67 Disable Boost Current

This command applies only to 3180 and 6180 Series models.

Function:	The G67 command cancels the Boost Current mode.
Units:	none
Range:	none
Default Mode:	Disable Boost Current
Command Format:	G67CRLF
Notes:	<p>Cancelling the Boost Current feature allows slightly shorter cycle times.</p> <p>The X field, if programmed, defines the <i>index</i> distance and direction.</p> <p>The F field, if programmed, becomes the <i>High Speed</i> velocity.</p>
Related G Codes:	G66 (Enable Reduce Current)

G68 Motor Windings Off

Function: The G68 command selects an average motor winding current level of zero at standstill.

Units: none

Range: none

Default Mode: Windings On

Command Format: G68CRLF

Notes: **The G68 command should only be used when no holding torque is required at standstill.**

When the Motor Windings Off function is active, an additional time delay is introduced during programmed motion cycles to allow winding current to build in the motor prior to motion and to decay after motion has stopped. This delay is approximately 50 milliseconds prior to motion and 50 milliseconds after motion has stopped. Therefore, the shortest possible time between moves is approximately 100 milliseconds.

The X field, if programmed, defines the *index* distance and direction.

The F field, if programmed, becomes the *High Speed* velocity.

Related G Codes: G69 (Motor Windings On)

G69 Motor Windings On

Function: The G69 command cancels the Motor Windings Off condition, causing current to be applied to the motor windings.

Units: none

Range: none

Default Mode: Windings On

Command Format: G69CRLF

Notes: When the Windings Off mode is inactive, motor winding current is applied at all times, providing holding torque at standstill and allowing slightly shorter cycle times.

The X field, if programmed, defines the *index* distance and direction.

The F field, if programmed, becomes the *High Speed* velocity.

Related G Codes: G68 (Motor Windings Off)

G76 Return To Electrical Home

Function:	This command will cause the Indexer to return to the location which has been designated as <i>Electrical Home</i> by performing an <i>index</i> move. This is an Absolute position of zero.
Units:	none
Range:	none
Default Mode:	none
Command Format:	G76CRLF
Notes:	<p>The direction for a Return To <i>Electrical Home</i> move is the reverse of the direction of the present Absolute position and the distance will be the present Absolute position value.</p> <p>The X field, if programmed, defines an <i>index</i> distance and direction.</p> <p>The F field, if programmed, becomes the <i>High Speed</i> velocity.</p>
Related RS232 Commands:	<p>H04 (<i>High Speed Mode</i>) H05 (<i>Low Speed Mode</i>) H08 (Return to <i>Electrical Home</i>) H09 (Set <i>Electrical Home</i>)</p>

G77 Set Electrical Home

Function:	This command causes the Indexer to establish the present mechanical position as <i>Electrical Home</i> .
Units:	none
Range:	none
Default Mode:	none
Command Format:	G77CRLF
Notes:	<p>The X field, if programmed, defines an <i>index</i> direction and distance.</p> <p>The F field, if programmed, becomes the <i>High Speed</i> velocity.</p>
Related RS232 Commands:	<p>H09 (Set <i>Electrical Home</i>)</p>

G78 Return To Mechanical Home

Function: This command tells the Indexer to perform a Return To *Mechanical Home* cycle.

Units: none

Range: none

Default Mode: none

Command Format G78CRLF

Notes: The Indexer begins a Return To *Mechanical Home* cycle by jogging at the rate programmed for the Home Speed parameter (L14). The direction of the motion is determined by the *Mechanical Home* Direction parameter (L08).

The Indexer will Jog until the Home Limit switch is activated, and will then ramp to a halt. The point at which the Home Limit switch was activated will be registered as the temporary Home position.

When motion ceases, the Indexer will *index* to the temporary Home position and will Jog at Low Speed (L12 value) until the Home Limit switch input becomes active and then inactive.

The Indexer then reverses direction and Jogs at Low Speed (L12 value) until the Home Limit switch becomes active again. This position is then established as the Absolute *Electrical Home* Position.

If a value other than 0 is programmed for the *Mechanical Home* Offset (L17) parameter, the Indexer will now *index* this direction and distance. This position is then established as the Absolute *Electrical Home* Position.

The X field, if programmed, defines an *index* distance and direction.

The F field, if programmed, becomes the *High Speed* velocity.

Related RS232 Commands:

- H04 (*High Speed Mode*)
- H05 (*Low Speed Mode*)
- H09 (*Set Electrical Home*)
- H10 (*Return to Mechanical Home*)

G79 Preload Absolute Position

Function:	Preloads the Electrical Absolute Position to the X value.
Units:	none
Range:	none
Default Mode:	none
Command Format:	G79 Xsnnnnnnnn CRLF
Notes:	If no X value is programmed, the Absolute value will be derived from the external field data inputs.

G90 Absolute Position Mode

Function:	This command selects the Absolute Position mode.
Units:	none
Range:	none
Default Mode:	Incremental mode
Command Format:	G90CRLF
Notes:	<p>When the Indexer is in the Absolute Position mode, any programmed move will be treated as an absolute distance from <i>electrical home</i>.</p> <p>The X field, if programmed, defines an <i>index</i> distance and direction.</p> <p>The F field, if programmed, becomes the <i>High Speed</i> velocity.</p> <p>The Auto Reverse feature will be disabled when operating in the Absolute Position mode.</p>

G91 Incremental Position Mode

Function:	This command selects the Incremental Position mode.
Units:	none
Range:	none
Default Mode:	Incremental mode
Command Format:	G91CRLF
Notes:	<p>When operating in the <i>Incremental Positioning</i> mode, each programmed move will be treated as an incremental distance from the present mechanical position.</p> <p>The X field, if programmed, defines an <i>index</i> distance and direction.</p> <p>The F field, if programmed, becomes the <i>High Speed</i> velocity.</p>

6.4 LINE DATA CODES

The data on a program line consists of a line number, a G code, a move distance or G code data (see Section 6.3), and a feed rate value or G code data.

The line data format is as follows:

Nnnn Gnn Xsnnnnnnnn FnnnnnnnCRLF

The fields can be loaded in any order or one at a time.

Once a line number has been addressed, it will remain addressed until one of the following occurs:

- 1) A different line is addressed (Nnnn).
- 2) Program execution is started (H1).
- 3) A Clear command is issued (*).
- 4) A Transfer Program Lines command is issued (H14).
- 5) A Clear Program Lines command is issued (H12).

When a program is started, the line which has been addressed will be the first line to be executed.

N Line Number

Function: This command will set the line pointer to the line specified by the "nnn" entry.

Units: none

Range: 0 through 400

Default: L41 value (at power up)

Command Format: NnnnCRLF

Notes: All program lines (0 to 400) are stored in nonvolatile, battery-backed RAM.

If the Line Number is 0, the Manual Data Interface mode will be selected. If this line is executed, the line pointer will remain at 0 upon completion of the line. If execution of the line is terminated by a Clear command or by detection of a line error, the line pointer will be set to the L41 value.

The commands allowed on this line 0 are:

Motion

N000 Xsnnnnnnnn Fnnnnnnn	(Index)
N000 G10 Xsnnnnnnnn Fnnnnnnn	(Index From Run)
N000 G36 Fnnnnnnn	(Strobe X Data)
N000 G38 Xsnnnnnnnn	(Strobe F And Index)
N000 G76	(Return To <i>Electrical Home</i>)
N000 G78	(Return To <i>Mechanical Home</i>)

Auxiliary Functions

N000 G04 Xnnnnnn	(Delay X Value)
N000 G29 Xsnnnnnnnn Fnn	(Preload Designated Parameter)
N000 G47 Xnnnnnn	(Output Condition X)
N000 G77	(Set <i>Electrical Home</i>)
N000 G79 Xsnnnnnnnn	(Preload Absolute Position)

Line Number continued

Mode Selection

N000 G27	(High Speed Mode)
N000 G28	(Low Speed Mode)
N000 G64	(Enable Reduced Current Mode)
N000 G65	(Cancel Reduced Current Mode)
N000 G66	(Enable Boost Current Mode)
N000 G67	(Cancel Boost Current Mode)
N000 G68	(Windings Off Mode)
N000 G69	(Windings On Mode)
N000 G90	(Absolute Mode)
N000 G91	(Incremental Mode)

Example:

Executing line 0 from a host computer.
The following is sent as one line (37 characters).

N0 G91 H1 X+1000 F2000 H1 X-1000 H1CRLF

Description:

N0 G91 H1	(set Incremental mode)
X+1000 F2000 H1	(execute a 1000 pulse move CW at 2000 pps)
X-1000 H1	(execute a 100 pulse move CCW at 2000 pps)

X Program Move And Direction

Function: This command defines the direction and distance of a move, or is the data field for a G codes.

Units: pulses or G code data

Range: -99,999,999 to +99,999,999 pulses

Default: none

Command Format: XsnnnnnnnnCRLF

Notes: G Codes which require an X data field are listed below:
 G04 Xnnnnnnn (delay X milliseconds)
 G11 Xnnn Fnnnn (subroutine call to line X, repeat F times)
 G12 Xnnn (go to line X)
 G20 Xnnnnnnnn Fnnn (branch to line F on input condition X)
 G22 Xnnnnnnnn (wait for condition X)
 G25 Xnnnn (Loop Start)
 G29 Xsnnnnnnn Fnn (Preload Designated Parameter)
 G47 Xnnnnnnn (output condition X)
 G48 Xs (start Jog cycle in X direction)
 G79 Xsnnnnnnnn (Preload Absolute Position)

When an X field that is not a data field for a G code is encountered during program execution, the Indexer will *index* the distance and direction programmed.

If the Incremental mode has been selected, the distance and direction will be relative to the position at the start of the motion.

If the Absolute mode has been selected, the direction and distance will be relative to the *Electrical Home* position.

If the Auto Reverse feature has been activated, the Indexer will automatically reverse direction at the end of the motion and will *index* the distance programmed for this parameter.

Example: X+1000CRLF sets the move for the program line to 1000 pulses in the plus direction.

see L11 [accel PPS] → 40000 = SLOW
 60000 = MED
 80000 = FAST

L12 [START SPEED] → 5000 = SLOW...
 15000 = MED
 20000 = FAST

F [PPS VELOCITY]

~~GOOD EXAMPLE~~
~~N0 H12~~ # Clear program
~~N0~~

GOOD EXAMPLE RUN

```

<01 ; TALK TO UNIT #01
L11 40000 ; ACCEL
L12 1000 ; START VEL
N0 H12 ; CLEAR
N0 H04 G91 X 20000 F15000
  
```

HI SET MODE DIST IN PULSES SPEED (PPS)

TO REPEAT, JUST TYPE "H12". TO CHG DIST, TYPE (X2000 H12)

F Program High Speed Feed Rate

- Function:** This command selects the rate to be used as the step rate when the Indexer is in the *High Speed* mode. It may also be used as the data field for a G codes.
- Units:** pulses per second or G Code field data
- Range:**
1 to 115,000 for L70=1
1 to 115,000 for L70=2
1 to 115,000 for L70=5
1 to 115,000 for L70=10
1 to 1,875,000 for L70=125
- Default:** none
- Command Format:** FnnnnnnnCRLF
- Notes:** G Codes which require an F data field are listed below:
G11 Xnnn Fnnnn (subroutine call to line X, repeat F times)
G20 Xnnnnnnnn Fnnn (branch to line F on input condition X)
G29 Xsnnnnnnnn Fnn (Preload Designated Parameter)
- When an F field that is not a data field for a G code is encountered during program execution, the Indexer will use this value as the *High Speed* value for the motion.
- If the value programmed for this parameter exceeds the value entered for the Ramp Frequency Limit (L71) parameter, the Ramp Frequency Limit (L71) parameter will be used as the default value for the F code.**
- Example:** F10000 CRLF sets the program feed rate to 10,000 pulses per second.

6.5 MISCELLANEOUS COMMANDS

Clear

- Function:** Activating the Clear command will cause an immediate termination of the current operation.
- Command Format:** * (ASCII 42) (no terminator required)
- Notes:** The * command will stop motion immediately, terminate program execution, cancel any paused motion and clear the RS232 buffer.
- Since the Clear command causes an immediate termination of motion, it may result in an inaccurate Absolute position count.**
- If data is being loaded, the load sequence will be terminated and the previously loaded value will be retained.
- If a delay is occurring, the delay will be terminated.

Feed Hold

- Function:** Activating the Feed Hold function will cause any motion that is occurring to come to a controlled stop. The absolute position count will remain accurate.
- Command Format:** \$ (ASCII 36) (no terminator required)
- Notes:** The rate at which the motor will decelerate to a stop when a Feed Hold is issued is determined by the value programmed for the Acceleration/Deceleration Limit (L11) parameter.
- To continue a motion cycle that was halted by a Feed Hold command, simply reactivate the Command that started the motion cycle.
- If you want to terminate the motion cycle that was in process, activate the Clear (*) function. If the Clear command is used in this instance, the absolute position count will remain accurate.

Program Stop

- Function:** This command will terminate program execution. Any motion or delay that is taking place will be allowed to finish. However, a new motion cycle will not be allowed to start.
- Command Format:** # (ASCII 35) (no terminator required)
- Notes:** If the Single Cycle mode of operation has been selected and a Repeat Count value has been programmed, the next Cycle Start (H01) command will cause the Indexer to use the remaining repeat count (rather than the repeat count plus 1 value).
- If you wish to execute the total Repeat Count Cycle, you must execute a Clear Command prior to the cycle start.
- Related L Codes:** L06 (Execution Format)
L47 (Repeat Count)

SECTION 7: DEDICATED SIGNAL OUTPUTS

NOTE: See section 3.2 for guidelines on using these open-collector outputs.

All Windings Off (\overline{AWO})

Pin Number: 

Function: The All Windings Off is an *open collector* output that permits monitoring of the state of the motor windings.

Notes: The output is inactive when current is applied to the motor and active when no current is applied.

CW/\overline{CCW}

Pin Number: 

Function: This *open collector* output permits monitoring of the direction of indexer motion.

Notes: The output is active when motion is in the CCW direction and inactive when motion is in the CW direction.

$\overline{Motion\ Busy}$

Pin Number: 

Function: Motion Busy is an *open collector* output that can be used to monitor indexer motion.

Notes: The output will be active when motion is taking place, and inactive when no motion is occurring.

$\overline{Position\ Error}$

Pin Number: 

Function: This *open collector* output permits monitoring of an *Index From Run Travel Limit Error*.

Notes: This output will become active if an *Index From Run Travel Limit (L16)* was exceeded.

A new motion command will deactivate this output.

Power Supply Common (V0)

Pin Number:

1 and 14

Function:


These pins will connect the power supply common of the indexer to the common of the external power supply.

Notes:

Use this connection point when providing a source voltage for Position Error, Motion Busy, All Windings Off, CW/CCW and Pulse outputs.

Pulse

Pin Number:



Function:

This *open collector* output can be used to monitor the pulse train that the indexer generates during motion.

Notes:

When a resolution of 1,2,5 or 10 is selected, the pulse train will be square waves. **This signal should not be used if the selected resolution is 1/125.**

The pulse train count is based on the rising edge of the pulses.

APPENDIX A L CODE LISTING AND DEFAULTS

L Code Listing

Indexer Parameters

L07 nnnn	Strobe Delay
L13 nnnnnnnn	Step Increment
L16 nnnnnnnn	Index From Run Travel Limit
L18 snnnnnnnn	CW Software Travel Limit
L19 snnnnnnnn	CCW Software Travel Limit
L20 n	Up/Down Feed Rate Override
L41 nnn	Auto Start Line Number
L45 n	Limit Switch Enable
L57 nnn	Strobe 0, Strobe 1 Delay
L67 n	Auto Reverse
L70 nnn	Resolution

RS232 Parameters

L21 nn	Device Identification Number
L22 nnnn	Baud Rate
L23 n	Character Length
L25 n	RS232 Parity
L26 n	Command Acknowledgement
L48 nnn	Program Line Count Designator
L49 nn	Parameter Transfer Designator
L50 nn	Parameter Transfer Count
L52 nnn	Buffer Warning Character
L55 nnn	Line Done Character
L56 nnn	Program Done Character
L98 nnn	Delay Between Continuous H Code Transmissions

Program Parameters

L06 n	Execution Format
L44 nnnn	Program Line Delay
L47 nnnnnnnn	Repeat Count
L51 n	Input/Output Mode Select

Feed Rate Parameters

L09 nnnnnnn	Jog Speed
L12 nnnnnnn	Low Speed
L14 nnnnnnn	Home Speed
L73 nnnnnnnn	Deviation Frequency

Ramp (Accel/Decel) Parameters


L11 nnnnnnnn	Acceleration/Deceleration
L71 nnnnnnnn	Ramp Frequency Limit
L72 n	Ramp Profile Select

Mechanical Home Parameters

L08 s Mechanical Home Direction
 L17 snnnnnnnn Offset From Mechanical Home

Backlash Compensation Parameters

L43 nnnn Delay Between Index And Backlash
 L66 snnnnnnnn Backlash Compensation



WIRING

NOTES ON RUNNING MOTORS

< 01 ; TALK TO UNIT 01

SELECTING THE UNIT

9600, N, 8, 1

DEFAULT BAUD/PARITY

= ; response "OK"

RESPONSE

< 008 ; TALK TO ALL UNITS

Factory Defaults Summary

Code	Function	L70=1	L70=2	L70=5	L70=10	L70=125
L06	Executlon Format	2	2	2	2	2
L07	Strobe Delay	0	0	0	0	0
L08	Mechanical Home Direction	+	+	+	+	+
L09	Jog Speed	1000	2000	5000	10000	125000
L11	Acceleratlon/Deceleratlon	1000	2000	5000	10000	125000
L12	Low Speed	300	600	1500	3000	37500
L13	Step Increment	1	2	5	10	125
L14	Home Speed	1000	2000	5000	10000	125000
L16	Index From Run Travel Limit	0	0	0	0	0
L17	Offset From Mechanical Home	+0	+0	+0	+0	+0
L18	CW Software Travel Limit	-0	-0	-0	-0	-0
L19	CCW Software Travel Limit	+0	+0	+0	+0	+0
L20	Up/Down Feedrate Override	0	0	0	0	0
L21	Device Identificatlon Number	01	01	01	01	01
L22	Baud Rate	9600	9600	9600	9600	9600
L23	Character Length	8	8	8	8	8
L25	RS232 Parity	1	1	1	1	1
L26	Command Acknowledgement	0	0	0	0	0
L41	Auto Start Line Number	1	1	1	1	1
L43	Delay Between Index and Backlash	50	50	50	50	50
L44	Program Line Delay	50	50	50	50	50
L45	Limit Switch Enable	0	0	0	0	0
L47	Repeat Count	0	0	0	0	0
L48	Program Line Count Designator	20	20	20	20	20
L49	Parameter Transfer Designator	0	0	0	0	0
L50	Parameter Transfer Count	0	0	0	0	0
L51	Input/Output Mode Select	0	0	0	0	0
L52	Buffer Warning Character	0	0	0	0	0
L55	Line Done Character	0	0	0	0	0
L56	Program Done Character	0	0	0	0	0
L57	Strobe 0 and Strobe 1 Delay	4	4	4	4	4
L66	Backlash Compensation	+0	+0	+0	+0	+0
L67	Auto Reverse	0	0	0	0	0
L71	Ramp Frequency Limit	115000	115000	115000	115000	1875000
L72	Ramp Profile Select	0	0	0	0	0
L73	Devlatlon Frequency	10	20	50	100	1250
L98	Delay between continuous H Codes	100	100	100	100	100

APPENDIX B H CODES

H01	Cycle Start
H02	Step Mode
H03	Jog Mode
H04	High Speed Mode
H05	Low Speed Mode
H06	CW Direction
H07	CCW Direction
H08	Return To Electrical Home
H09	Set Electrical Home
H10	Return To Mechanical Home
H11	Clear Program Line
H12	Clear Program Lines Using L48
H13	Transfer Program Line
H14	Transfer Program Lines Using L48
H15	Transfer Current Line Number
H16	Transfer Parameters
H17	Transfer Absolute Electrical Position
H18	Transfer Motion Status
H19	Transfer Mode Status
H20	Transfer Output Status
H21	Transfer Conditional Input Status
H23	Transfer Software Revision Level
H24	Program Trace Mode On
H25	Program Trace Mode Off
H28	Transfer Switch Input Status
H29	Transfer Program Execution Time
H30	Start Index From Run Cycle
H31	Target Velocity Increase
H32	Target Velocity Decrease
H33	Incremental Position Mode
H34	Absolute Position Mode
H35	Motor Windings On
H36	Motor Windings Off
H37	Enable Boost Current
H38	Disable Boost Current
H39	Enable Reduce Current
H40	Disable Reduce Current
H41	Transfer Remaining Repeat Value
H60	Transfer Present Velocity
H85	Transfer Motion Error Status
H86	Transfer Data Error Status
H87	Transfer Program Error Line Number
H88	Transfer Active Cycle
H99	Transfer Unit Type

APPENDIX C IMMEDIATE COMMANDS

!Fnnnnnnn	Feed Rate Override
!L47 nnnnnnnn	Repeat Count
!L48 nnn	Program Line Count Designator
!L49 nn	Parameter Transfer Designator
!L50 nn	Parameter Transfer Count
!L52 nnn	Buffer Warning Character
!L55 nnn	Line Done Character
!L56 nnn	Program Done Character
!L57 nnn	Strobe 0, Strobe 1 Delay
!L98 nnn	Delay Between Continuous H Code Transmissions
!H04	High Speed Mode
!H05	Low Speed Mode
!H13	Transfer Program Line
!H15	Transfer Current Line Number
!H16	Transfer Parameters
!H17	Transfer Absolute Electrical Position
!H18	Transfer Motion Status
!H19	Transfer Mode Status
!H20	Transfer Output Status
!H21	Transfer Conditional Input Status
!H23	Transfer Software Revision Level
!H24	Program Trace Mode On
!H25	Program Trace Mode Off
!H28	Transfer Switch Input Status
!H29	Transfer Program Execution Time
!H31	Target Velocity Increase
!H32	Target Velocity Decrease
!H41	Transfer Remaining Repeat Value
!H60	Transfer Present Velocity
!H85	Transfer Motion Error Status
!H86	Transfer Data Error Status
!H87	Transfer Program Error Line Number
!H88	Transfer Active Cycle

APPENDIX D MISCELLANEOUS COMMANDS

! (ASCII 33)	Immediate Command
%Hnn	Activate Continuous H Code Transfer Mode
Nnnn	Line Number
Gnn	Preparatory Command
Xsnnnnnnnn	Program Index Distance or G Code data field
Fnnnnnnn	Program Feed Rate or G Code data field
Xoff (ASCII 19)	Stop Transmission
Xon (ASCII 17)	Resume Transmission
^H (ASCII 8)	Backspace And Delete
^X (ASCII 24)	Delete RS232 Buffer
<00CR	All Devices Active Mode
<00&	All Devices Listen Mode
<00@	Cancel Listen Mode For All Devices
<nnCR	Device Active
<nn?	Device Active And Acknowledge ID
nn&	Device Listen Mode
nn@	Device Cancel Listen Mode And Become Active
? (ASCII 63)	Device Acknowledge ID
* (ASCII 42)	Clear
\$ (ASCII 36)	Feed Hold
# (ASCII 35)	Program Stop
/ (ASCII 47)	Transfer Normal Buffer Character Count Remaining
\ (ASCII 92)	Transfer Immediate Buffer Character Count Remaining

Notes:

"s" is an ASCII sign (+ or -)

"n" is an ASCII number (0 to 9)

The remaining symbols are ASCII characters (decimal value shown)

APPENDIX E G CODE LISTING

G04 Xnnnnnn	Dwell Time
G10 Xsnnnnnnn	Start Index From Run
G11 Xnnn Fnnnn	Call a Subroutine
G12 Xnnn	Go To Line Number
G20 Xnnnnnnnn Fnnn	Conditional Branch
G22 Xnnnnnnnn	Wait For Input
G23	Increment Jog Cycle Frequency
G24	Decrement Jog Cycle Frequency
G25 Xnnnn	Loop Start
G26	Loop End
G27	High Speed Mode
G28	Low Speed Mode
G29 Xsnnnnnnnn Fnn	Preload Designated Parameter
G30	End Of Program
G31	Program Stop
G32	Return From Subroutine
G36	Strobe X Code Data
G37	Strobe N Code Data
G38	Strobe F Code Data
G47 Xnnnnnn	Set Output Condition
G48 Xs	Start Jog Cycle
G49	Stop Jog cycle
G64	Enable Reduce Current
G65	Disable Reduce Current
G66	Enable Boost Current
G67	Enable Boost Current
G68	Motor Windings Off
G69	Motor Windings On
G76	Return To Electrical Home
G77	Set Electrical Home
G78	Return To Mechanical Home
G79 Xsnnnnnnnn	Preload Absolute Position
G90	Absolute Position Mode
G91	Incremental Position Mode

APPENDIX G CABLE INFORMATION

Cables For Serial I/O Connections

The following cables are available from Superior Electric for *serial* I/O connections:
(25-pin male "D" connector on one end, 9-pin female "D" connector on other)

Length	Part Number
5 feet (1.5m)	B216059-001
10 feet (3m)	B216059-002

Cables For Parallel I/O Connections

The following cables are available from Superior Electric for *parallel* I/O connections:
(25-pin male "D" connector on each end)

Length	Part Number
5 feet (1.5m)	C215851-007
10 feet (3m)	C215851-008

APPENDIX H TYPICAL PLC INTERFACE

A PLC can be used to provide the inputs required to run a SLO-SYN Indexer through the *Parallel I/O* interface. Figure H1 shows how the typical switch panel connection can be translated to a PLC connection. Please refer 5.1 through 5.3 for all connection information and timing.




Figure H1A, Typical Switch Panel Connection




Figure H1B, Corresponding PLC Interface

Note: An External +5Vdc is required for the Corresponding PLC Interface. The Common on this Supply (-) must be connected to pin 1 or 14 on the Parallel I/O connector.

APPENDIX I APPLICATION PROGRAM EXAMPLE




Figure I-1

Application

- A Single Axis Table With a 5-pitch leadscrew, 5 revolutions of a 200 step/rev motor to move a table 1.000 inch (each motor step= 0.001 inch movement). A Stepping motor Drives the leadscrew.
- Five Inputs to the Indexer are required (see Figure I-2).
 - CW Overtravel Limit (CW Limit) and CCW Overtravel Limit (CCW Limit)
Prevents mechanical damage to the table.
 - Home Limit Switch (Home Limit)
Indicates the *Mechanical Home* Position.
 - Foot Switch (Input 1)
Initiates a material fill cycle.
 - Initialize Switch, Power Turn On (Cycle Start)
Initiates a *Mechanical Home* cycle and moves to the "Load" Position.
- One Output from the Indexer is required (see Figure I-2).
 - Output 1
Used to control the Fill Head through a Solid State Relay.
- The CW & CCW "soft" Limits are set for 1" inside the Overtravel limit switches.

Writing Your Own Program

1. Thoroughly familiarize yourself with the Operator Manual, where the information is, what it is, how it is presented, before you start.
2. Define your objectives. Write it down and keep it simple.
Do a *Mechanical Home Cycle*.
Move table to "Load" Position (-5" from Home Position).
Wait for closure of foot switch (Input 1).
Move table to "Fill" Position (+5" from Home Position).
Delay 1/10 of a second.
Enable Output to open valve (Output 1).
Delay 5 seconds while container fills.
Disable Output to close valve (Output 1).
Move table to "Load" Position (-5" from Home Position).
Wait foot switch release (Input 1).
3. List out the system parameters (L Code) of the Indexer. See APPENDIX A for a complete L Code Listing and Section 5.1 for detailed information about the L Code.

4. Decide on Your parameter settings and write them down. The Indexer *default* values should be used if possible. A complete listing of Indexer *Default Values* is given in APPENDIX A of this manual.

L06 2	(Automatic Execution Format)
L08 +	(<i>Mechanical Home</i> Direction)
L17 -5000	(<i>Mechanical Home</i> Offset) (Distance to "Load" Position from <i>Mechanical Home</i>)
L18 +7000	(CW Travel Limit) (1" from CW Limit Switch)
L19 -7000	(CCW Travel Limit) (1" from CCW Limit Switch)
L41 001	(Auto Start Line Number)
L70 001	(Resolution)
L72 0	(Trapezoidal Ramp Profile)

5. Break the objective down into G codes and discrete moves and velocity. Refer to Sections 6.3 and 6.4 of this manual for detailed descriptions of G code operation and Line Data Codes. A sample "Programming Worksheet" has been provided in APPENDIX F. Now Proceed as follows:

- a) Write down the G Codes you will be programming next to the objective.
G78 Do a *Mechanical Home Cycle* and Move table to "Load" Position (-5" from Home Position).
G22 X21 Wait for closure of foot switch (Input 1).
G04 X100 Delay 1/10 of a second.
G47 X01 Enable Output to open valve (Output 1).
G04 X5000 Delay 5 seconds while container fills.
G47 X00 Disable Output to close valve (Output 1).
G22 X20 Wait foot switch release (Input 1).

- b) Write Down the Move value (X) and Velocity (F) next to the objective.
G90 X+5000 F1000 Move table to "Fill" Position (+5" from Home Position).
X-5000 Move table to "Load" Position (-5" from Home Position).

- c) Decide if Subroutines, Loops or Branches will be useful.

- d) Now assemble all these sections into the desired sequence.

G78	(<i>Mechanical Home Cycle</i> with offset to "Load" Position)
G22 X21	(Wait for Foot Switch closure)
G90 X+5000 F1000	(set <i>Absolute Position</i> Mode and move to "Fill" Position +5000)
G04 X100	(Delay 1/10 of a second)
G47 X01	(Output 1 active, open valve)
G04 X5000	(Delay 5 seconds)
G47 X00	(Output 1 inactive, close valve)
X-5000	(Move to "Load" Position, <i>Absolute Position</i> -5000)
G22 X20	(Wait for Foot Switch opening)

e) Assign line numbers (N values)

- N001 G78 (Mechanical Home Cycle with offset to "Load" Position)
- N002 G22 X21 (Wait for Foot Switch closure)
- N003 G90 X+5000 F1000 (set *Absolute Position* Mode and move to "Fill" Position +5000)
- N004 G04 X100 (Delay 1/10 of a second)
- N005 G47 X01 (Output 1 active, open valve)
- N006 G04 X5000 (Delay 5 seconds)
- N007 G47 X00 (Output 1 inactive, close valve)
- N008 X-5000 (Move to "Load" Position, *Absolute Position* -5000)
- N009 G22 X20 (Wait for Foot Switch opening)
- N010 G12 X2 (Continue at Line 2)

6. Be patient. Plan on going through several iterations and having to make changes before your program works as you envision it would work.

If you have difficulty, the following ideas may help:

- a) Double check your program and L Codes (transfer them from the Indexer) to be sure they were entered correctly.
- b) Use the "Trace Mode" (H24 page 6-45) to check each step of the program operation.
- c) Use the fault code transfer commands (H85, H86 and H87) and Status Transfer commands (H18, H19, H20, H21, H27 and H28) to check system operation.
- d) Double check system wiring, especially any connections between components.




Figure I-2
Diagram of Application Example

GLOSSARY

- Absolute Positioning** In the Absolute Positioning mode, all positioning commands are expressed as with respect to the absolute zero position. For example, if the motor is +100 steps from zero and the next motion command is +75, the motor will be driven 25 steps in the minus direction so that it will then be located at the +75 position.
- Backlash** When a load is driven through a mechanical device such as a gear train, play or "lash" in the mechanical system may cause the motor to make several steps before the load actually begins to move. The SLO-Syn Indexer has a backlash Compensation feature to help prevent the position errors which can be caused by "lash" in the mechanical system. Using the L66 parameter, the operator selects the direction and the number of pulses to be used for backlash compensation. Whenever a move is made in the selected direction, the Indexer adds the selected number of pulses to the move. It then reverses direction and moves the selected number of pulses again, thereby compensating for play in the system.
- Baud Rate** The number of binary bits that will be transmitted in serial fashion over a communications interface such as RS232.
- BCD (Binary Coded Decimal)** A system in which the individual digits expressing a number in decimal notation are represented by a four-bit binary numeral. For example, the number twenty-three is represented by 0010 0011 in the 8-4-2-1 type of binary codes decimal notation.
- Daisy Chain** An arrangement whereby up to 99 Indexers can communicate with a single host using only one serial port. Each Indexer in the chain must be assigned a unique device address to allow the host to communicate with each indexer individually. The host can also communicate with all indexers simultaneously, if necessary.
- Default** Each Indexer parameter is assigned a default value at time of manufacture. The default value will be used for a parameter unless the user programs it with a different value.
- Drive Resolution** The Drive Resolution is used to establish the number of pulses the drive must provide to the motor to accomplish one full motor step. A drive with a resolution of 1 requires one pulse to complete one full step, or 200 pulses to complete a full revolution of the motor shaft.
- Electrical Home** Electrical Home is the position where the absolute position count is zero. All Absolute positioning moves are made with respect to this location.
- High Speed** The High Speed rate is the speed used when rapid motion is needed and maximum torque is not required. The Indexer starts at the Low Speed rate and then ramps up to the High Speed at the programmed acceleration rate. The Indexer ramps down to the Low Speed rate and then stops at the end of the motion.
- Incremental Positioning** In this positioning mode, the motor will move the programmed distance in the chosen direction each time an index command is given. Each positioning command represents the distance which the motor is to move from the present position.

Index

An Index motion is one in which the motor is driven a specific number of steps when the Index motion command is given. In the case of the SLO-SYN Indexer, the X field represent the number of steps to be taken when an Index command is issued.

Jog Mode

The Jog Mode provides continuous motor motion when a CW (H06) or CCW (H07) command is given. The motor will operate in the selected direction until a Feed Hold (\$) or a Clear (*) command is issued.

Low Speed

The Low Speed is a rate to which the motor will start without acceleration or deceleration. When motion is to be done at the High Speed rate, the motor will be started at the Low Speed rate and then accelerated to the High Speed rate. When stopping at the end of motion, the motor will be decelerated to the Low Speed and then to a stop.

When setting the Low Speed rate, be sure to select a rate to which the motor can be started without acceleration.

Mechanical Home

The Mechanical Home position is used to establish a physical location as home. Using the Return To Mechanical Home cycle, the user can reference all electrical information to this physical location. The Return To Mechanical Home cycle establishes Electrical Home as well as Mechanical Home.

Open Collector

An output device that uses a transistor to simulate a switch. One end of the switch is at ground (V0) and the other end is accessible for connection to the device which must be controlled.

Parallel I/O

A Parallel I/O interface is one in which all of the bits of a command are processed simultaneously. The SLO-SYN Indexer uses a Parallel I/O interface for operation from a switch panel or the SSP-100 Programmer.

Pull-Up Resistor

A resistor that is connected to the accessible end of an open collector output to permit monitoring of the output when it is in the off state.

Serial I/O

A Serial I/O interface is a type of information transfer performed by a digital computer or other device in which all bits of a word or command are handled sequentially.

Step Mode

When operating in the Step mode, the Indexer will drive the motor the Step distance each time a motion command is given.

WARRANTY AND LIMITATION OF LIABILITY

Superior Electric (the "Company"), Bristol, Connecticut, warrants to the first end user purchaser (the "purchaser") of equipment manufactured by the Company that such equipment, if new, unused and in original unopened cartons at the time of purchase, will be free from defects in material and workmanship under normal use and service for a period of one year from date of shipment from the Company's factory or a warehouse of the Company in the event that the equipment is purchased from the Company or for a period of one year from the date of shipment from the business establishment of an authorized distributor of the Company in the event that the equipment is purchased from an authorized distributor.

THE COMPANY'S OBLIGATION UNDER THIS WARRANTY SHALL BE STRICTLY AND EXCLUSIVELY LIMITED TO REPAIRING OR REPLACING, AT THE FACTORY OR A SERVICE CENTER OF THE COMPANY, ANY SUCH EQUIPMENT OR PARTS THEREOF WHICH AN AUTHORIZED REPRESENTATIVE OF THE COMPANY FINDS TO BE DEFECTIVE IN MATERIAL OR WORKMANSHIP UNDER NORMAL USE AND SERVICE WITHIN SUCH PERIOD OF ONE YEAR. THE COMPANY RESERVES THE RIGHT TO SATISFY SUCH OBLIGATION IN FULL BY REFUNDING THE FULL PURCHASE PRICE OF ANY SUCH DEFECTIVE EQUIPMENT. This warranty does not apply to any equipment which has been tampered with or altered in any way, which has been improperly installed or which has been subject to misuse, neglect or accident.

THE FOREGOING WARRANTY IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, and of any other obligations or liabilities on the part of the Company; and no person is authorized to assume for the Company any other liability with respect to equipment manufactured by the Company. The Company shall have no liability with respect to equipment not of its manufacture. **THE COMPANY SHALL HAVE NO LIABILITY WHATSOEVER IN ANY EVENT FOR PAYMENT OF ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING, WITHOUT LIMITATION, DAMAGES FOR INJURY TO ANY PERSON OR PROPERTY.**

Written authorization to return any equipment or parts thereof must be obtained from the Company. The Company shall not be responsible for any transportation charges.

IF FOR ANY REASON ANY OF THE FOREGOING PROVISIONS SHALL BE INEFFECTIVE, THE COMPANY'S LIABILITY FOR DAMAGES ARISING OUT OF ITS MANUFACTURE OR SALE OF EQUIPMENT, OR USE THEREOF, WHETHER SUCH LIABILITY IS BASED ON WARRANTY, CONTRACT, NEGLIGENCE, STRICT LIABILITY IN TORT OR OTHERWISE, SHALL NOT IN ANY EVENT EXCEED THE FULL PURCHASE PRICE OF SUCH EQUIPMENT.

Any action against the Company based upon any liability or obligation arising hereunder or under any law applicable to the sale of equipment, or the use thereof, must be commenced within one year after the cause of such action arises.

ASSIGN AN ID TO SINGLE DEVICE, AND THEN MAKE IT ACTIVE

1	<00 0 2	; ALL ACTIVE
2	L21 _u 12	; SETS DEVICE ID = 1
3	<012	; DEVICE #1 ACTIVE
4	<01@	; DISABLE "LISTEN" MODE SO WE CAN RECEIVE RESPONSES

PREP CONFIG

W/ 10/10/2003


SEE PP 6-78

FOR EXAMPLE RUN

SEE PP AP-12 FOR NAME PROGRAMS, ETC

DISTRIBUTION COAST-TO-COAST AND INTERNATIONAL Superior Electric products are available nationwide through an extensive authorized distributor network. These distributors offer literature, technical assistance and a wide range of models off the shelf for fastest possible delivery.

In addition, Superior Electric sales engineers and manufacturers' representatives are conveniently located to provide prompt attention to customers' needs. Call the nearest office listed for ordering and application information or for the address of the closest authorized distributor.



IN U.S.A. AND CANADA

383 Middle Street
Bristol, CT 06010
Tel: (203) 582-9561
TWX: 710-454-0682

Customer Service: 1 800 227-6470
Product Application: 1 800 227-6471
Product Literature Request: 1 800 766-7171
Fax: 1 800 766-6366

IN EUROPE

Superior Electric Nederland B.V.
Koperwerf 33
2544 EM The Hague, Netherlands
Tel: 31 70 3 679590
TELEX: 31436 Supe nl
FAX: 011 31 70 3 296274

These products are sold subject to the standard Limitation of Liability and/or Warranty of The Superior Electric Company, The American Superior Electric Company, Ltd., or Superior Electric Nederland B.V.

The right to make engineering refinements on all products is reserved. Dimensions and other details are subject to change.

SUPERIOR ELECTRIC

WARNER ELECTRIC

383 Middle Street • Bristol, CT 06010
(203) 582-9561 • Fax (203) 589-2136

